















## Servo motors +BATT +BATT J4 TP21 TP\_SERVO\_CONTROL\_02 J5 CONN\_SERVO\_01 CONN\_SERYO\_02 TP22 TP\_SERVO\_CONTROL\_01 SERVO\_CONTROL\_02 SERVO\_CONTROL\_01 TP23 TP\_SERVO\_CURR\_RAW\_02 TP24 TP\_SERVO\_CURR\_02 R19 TP26 TP\_SERVO\_CURR\_01 TP25 TP\_SERVO\_CURR\_RAW\_01 1 k 1 k SERVO\_CURR\_02 SERVO\_CURR\_01 R21 0.1 C14 100nF C15 100nF R22 0.1 C16 100nF C17 100nF $\dot{\uparrow}$ GND GND GND GND GND GND +BATT J6 CONN\_SERVO\_03 TP27 TP\_SERVO\_CONTROL\_03 SERVO\_CONTROL\_03 R23 R24 TP29 TP\_SERVO\_CURR\_03 SERVO\_CURR\_03 TP28 TP\_SERVO\_CURR\_RAW\_03 1k R25 0.1 C19 100nF C18 100nF GND GND GND