# C11160/C11165 Driver Circuit for CCD Linear Image Sensor

# Components

(1)Circuit Board × 1



(2)Power Supply Cable x 1



(3)USB Cable × 1



(4)Quick Manual × 1



#### (5)CD(Software Installer)× 1



- \_USB Camera Module Control Driver for Windows
- \_Driver Circuit for Image Sensor Control Library for Windows
- \_Driver Circuit for Image Sensor Control Software for Windows
- \_Various Operation manuals
  - \_C11160/C11165 Driver Circuit for CCD Linear Image Sensor Instruction Manual
  - \_USB Camera Module Control Driver Install Manual
  - \_Driver Circuit for Image Sensor Control Library Function Specifications
  - \_Driver Circuit for Image Sensor Control Software Instruction Manual
  - \_C11160/C11165 Driver Circuit for CCD Linear Image Sensor Quick Manual(This Manual)

## **Precautions**

- (1) Do not allow any penetration of Liquids into the Circuit Board. Danger of causing Circuit Boardmalfunctions.
- (2) Do not use in Combustible Environment (Combustible Gasses, High-density Oxygen, etc.).
- (3) Maintenannce and Repair to be performed only by the Maker or by technicians authorized by the Maker.
- (4) Do not twist, bend or cut the cables. May cause damages.
- (5) Do not take it apart or perform modifications under any circumstances. May cause malfunctions.
- (6) Do not subject to excessive shocks (dropping, collision, etc.). May cause damages or malfunctions.
- (7) Please study the method of use of this product before using.

For other precautionary measures, refer to the "C11160/C11165 Driver Circuit for CCD Linear Image Sensor Instruction Manual"

#### Hamamatsu Photonics KK

HomePage http://www.hamamatsu.com/

1126-1,lchino-Cho,Higashi-Ku,Hamamatsu-City,Shizuoka Pref.,435-8558,Japan Phone:(81)53-434-3311 Fax:(81)53-434-5184


Document Number:K46-B60075 Document Revision 1.00:02.Dec.2009

## Setup

### 1. Equipment connection

Connect each of the equipment by to the fllowing procedure.

- (1)Connect the Power Supply cable to the connector.
- (2)Connect the "B connector" of the USB cable to the "USB connector" of the Circuit Board.
- (3)Connect the "A connector" of the USB cable to the "USB connector" of the PC.





2.Installation of Driver software (case of WindowsXP) (1)When PC is started after the completion of

"1.Equipment connection"."Found New Hardware Wizerd"is started,comfirm that

"HPK xxxxx"(xxxxx:Product number) is displayed, click the radio button for "Install from a list location(Advanced)" and click "Next>".



\*example of "C10785".

(2)In the "Select Search and Install Options" window, click the radio butt on for "Search for the suitable driver in the following locations", select the checkbox for "Search removable media [Floppy, CD-ROM,...] " and click "Next>".




(3)After the necessary filed are copied, confirm the "Completing Found New Hardware Wizerd" and "HAMAMATSU USB Camera Module" screens and then click "Finish".

The completes the driver installation.



(4)After the installation is comp lete,right-click on "My Computer" and select "Properties". The "system properties" will be displayed, open the "Device Manager" in the "Hardware "tab and confirm that" HAMAMATSU USB Camera Module is displyed.



For more information on how to insdtall the Software, see the "USB Camera Module Control Driver Installation Manual".

# 3. About installation of Application software.

To Use this product, the control of the Circuit Board is performed by the supplied application software.

Please refer "Driver Circuit for Image Sensor Control Software Instruction Manual" inside the include CD-ROM for the installation method and method of the supplied application software.