

Bambu Lab P1S

HMS Error Code Quick Reference

Scan QR codes to access troubleshooting guides

Generated: 2/5/2026 by Antony Rinaldi

HMS 0300-0100-0001-0003: The heatbed temperature is abnormal; the heater is over temperature.

**X1 series/P1 series/
A1Mini/A1/H2 series/P2
series**



Scan for article

HMS 0300-0100-0001-0006: The heatbed temperature is abnormal; the sensor may have an short circuit.

**X1 series/P1 series/A1
mini**



Scan for article

HMS 0300-0100-0001-0007: The heatbed temperature is abnormal; the sensor may have an open circuit. circuit.

**X1 series/P1 series/A1
mini**



Scan for article

HMS 0300-0100-0001-0008: An abnormality occurs during the heating process of the heatbed. The heating modules may be broken.

**X1 series/P1 series/A1/
A1Mini**



Scan for article

HMS 0300-0100-0001-000A: The heatbed temperature control is abnormal, the AC board may be broken.

**X1 series/P1 series/
A1Mini/A1/H2 series**



Scan for article

HMS 0300-0100-0003-0008: The temperature of the heated bed exceeds the limit and automatically adjusts to the limit temperature.

**X1 series/P1 series/A1/
A1Mini**



Scan for article

HMS 0300-0200-0001-0001: The nozzle temperature is abnormal, the heater may be short circuit.

**X1 series/P1 series/A1
mini/A1**



Scan for article

HMS 0300-0200-0001-0002: The nozzle temperature is abnormal, the heater may be open circuit.

**X1 series/P1 series/
A1Mini/A1**



Scan for article

HMS 0300-0200-0001-0003: The nozzle temperature is abnormal,the heater is over temperature.

**X1 series/P1 series/
A1Mini/A1**



Scan for article

HMS 0300-0200-0001-0006: The nozzle temperature is abnormal,the sensor may be short circuit.

**X1 series/P1 series/
A1Mini/A1**



Scan for article

HMS 0300-0200-0001-0007: The nozzle temperature is abnormal,the sensor may be open circuit.

**X1 series/P1 series/
A1Mini/A1**



Scan for article

HMS 0300-0300-0001-0001: The hotend cooling fan speed is too slow or stopped

**X1 series/P1 series/A1/
A1 mini**



Scan for article

HMS 0300-0300-0002-0002: The speed of hotend fan is slow.

X1 series/P1 series/A1/
A1 mini



Scan for article

HMS 0300-0400-0002-0001: The speed of part cooling fan if too slow or stopped.

Aliases: 0300-3100-0001-0001

X1 series/P1 series



Scan for article

HMS 0300-0600-0001-0001: Motor-A has an open-circuit. There may be a loose connection, or the motor may have failed.

Aliases: 0300-0700-0001-0001, 0300-0800-0001-0001

X1 series/P1 series/A1
mini



Scan for article

HMS 0300-0600-0001-0002: Motor-A has a short-circuit. It may have failed.

Aliases: 0300-0700-0001-0002, 0300-0800-0001-0002

X1 series/P1 series/A1
mini



Scan for article

HMS 0300-0600-0001-0003: The resistance of Motor-A is abnormal, the motor may have failed.

Aliases: 0300-0700-0001-0003, 0300-0800-0001-0003

X1 series/P1 series/A1
mini/H2 series



Scan for article

HMS 0300-0A00-0001-0001: The sensitivity of heatbed force sensor 1/2/3 is too high.

Aliases: 0300-0B00-0001-0001, 0300-0C00-0001-0001

X1 series/P1 series



Scan for article

HMS 0300-0A00-0001-0002: The sensitivity of heatbed force sensor 1/2/3 is low.

Aliases: 0300-0B00-0001-0002, 0300-0C00-0001-0002

X1 series/P1 series



Scan for article

HMS 0300-0A00-0001-0003: The sensitivity of heatbed force sensor 1/2/3 is too low.

Aliases: 0300-0B00-0001-0003, 0300-0C00-0001-0003

X1 series/P1 series



Scan for article

HMS 0300-0A00-0001-0004: An external disturbance was detected on force sensor 1. The heatbed plate may have touched something outside the heatbed.

Aliases: 0300-0B00-0001-0004, 0300-0C00-0001-0004

X1 series/P1 series



Scan for article

HMS 0300-0A00-0001-0005: Force sensor 1 detected unexpected continuous force. The heatbed may be stuck, or the analog front end may be broken.

Aliases: 0300-0B00-0001-0005, 0300-0C00-0001-0005

X1 series/P1 series



Scan for article

HMS 0300-0D00-0001-0003: The build plate is not placed properly.

Aliases: 0300-0D00-0001-0004, 0300-0D00-0001-0005, 0300-0D00-0001-0006, 0300-0D00-0001-0007, 0300-0D00-0001-0008, 0300-0D00-0001-0009, 0300-0D00-0001-000A, 0300-0D00-0002-0003, 0300-0D00-0002-0004, 0300-0D00-0002-0005, 0300-0D00-0002-0006, 0300-0D00-0002-0007, 0300-0D00-0002-0008, 0300-0D00-0002-0009, 0300-0D00-0002-000A

X1 series/P1 series/A1
mini/A1



Scan for article

HMS 0300-0D00-0001-000B: The Z axis motor seems to be stuck when moving. Please check if there is any foreign matter on the Z sliders or Z timing belt wheels.

X1 series/P1 series/A1/
A1 mini



Scan for article

HMS 0300-0D00-0002-0001: Heatbed homing abnormal: there may be a bulge on the heatbed or the nozzle tip may not be clean.

X1 series/P1 series/A1
mini



Scan for article

HMS 0300-0F00-0001-0001: Abnormal accelerometer data detected. Please try to restart the printer.

X1 series/P1 series/A1



Scan for article

HMS 0300-1000-0002-0001: The 1st order mechanical resonance mode of X axis is low.

Aliases: 0300-1100-0002-0001

X1 series/P1 series/A1
mini/A1



Scan for article

HMS 0300-1000-0002-0002: The resonance frequency of the X axis differs greatly from last calibration. Please clean the carbon rod and rerun the machine calibration afterward

Aliases: 0300-1100-0002-0002

X1 series/P1 series/A1



Scan for article

HMS 0300-1200-0002-0001: The front cover of the toolhead fell off.

X1 series/P1 series



Scan for article

HMS 0300-1300-0001-0001: The current sensor of Motor-A is abnormal. This may be caused by a failure of the hardware sampling circuit.

Aliases: 0300-1400-0001-0001, 0300-1500-0001-0001

X1 series/P1 series



Scan for article

HMS 0300-1D00-0001-0001: The position sensor of extrusion motor is abnormal. The connection to sensor may be loose.

X1 series/P1 series/
A1Mini/A1



Scan for article

HMS 0300-4000-0002-0001: Data transmission over the serial port is abnormal; the software system may be faulty.

X1 series/P1 series/A1
mini



Scan for article

HMS 0300-4100-0001-0001: The system voltage is unstable; triggering the power failure protection function.

X1 series/P1 series/A1
mini/A1/H2 series/P2
series



Scan for article

HMS 0300-9100-0001-0006: The temperature of chamber heater 1 is abnormal. The sensor may have a short circuit.

Aliases: 0300-9200-0001-0006

X1 series/P1 series



Scan for article

HMS 0300-9100-0001-0007: The temperature of chamber heater 1 is abnormal. The sensor may have an open circuit.

Aliases: 0300-9200-0001-0007

X1 series/P1 series



Scan for article

HMS 0300-9400-0003-0001: Chamber cooling may be too slow. You can open the chamber to help cooling if the gas in chamber is non-toxic.

X1 series/P1 series



Scan for article

HMS 0300-A800-0001-0001: AMS power supply abnormality, possibly due to AMS damage or a short circuit in the AMS interface, or too many AMS connections. Please check if it is correctly connected.

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0500-0100-0002-0001: The media pipeline is malfunctioning.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0100-0002-0002: USB camera is not connected.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0100-0002-0003: USB camera is malfunctioning.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0100-0003-0004: Not enough space in SD Card.

**X1 series/P1 series/
A1Mini**



Scan for article

HMS 0500-0100-0003-0005: Error in SD Card.

**X1 series/P1 series/
A1Mini**



Scan for article

HMS 0500-0100-0003-0006: Unformatted SD Card.

**X1 series/P1 series/
A1Mini**



Scan for article

HMS 0500-0200-0002-0001: Failed to connect internet, please check the network connection.

Aliases: 0500-0200-0002-0002, 0500-0200-0002-0003, 0500-0200-0002-0005

**X1 series/P1 series/
A1Mini/H2 series/P2S**



Scan for article

HMS 0500-0200-0002-0002: Failed to login device.

**X1 series/P1 series/
A1Mini**



Scan for article

**HMS 0500-0200-0002-0004: Unauthorized user:
please check your account information.**

**X1 series/P1 series/
A1Mini/H2 series/P2S**



Scan for article

**HMS 0500-0200-0002-0006: Liveview service is
malfunctioning.**

**X1 series/P1 series/
A1Mini/H2 series**



Scan for article

**HMS 0500-0300-0001-0001: The MC module is
malfunctioning. Please restart the device.**

**X1 series/P1 series/
A1Mini/A1**



Scan for article

HMS 0500-0300-0001-0002: The toolhead is malfunctioning. Please restart the device.

X1 series/P1 series/
A1Mini/A1/H2 series/P2S



Scan for article

HMS 0500-0300-0001-0003: The AMS module is malfunctioning. Please restart the device.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0300-0001-0004: The Filament Buffer module is malfunctioning. Please restart the device.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0300-0001-000A: System state is abnormal. Please restore factory settings.

X1 series/P1 series/
A1Mini/P2S/H2 series



Scan for article

HMS 0500-0300-0001-000B: The screen is malfunctioning.

X1 series/P1 series/
A1Mini



Scan for article

HMS 0500-0300-0002-000C: Wireless hardware error: please turn off/on WiFi or restart the device.

X1 series/P1 series/
A1Mini/P2S



Scan for article

HMS 0500-0300-0002-000E: Some modules are incompatible with the printer's firmware version, which may affect use. Please go to the "Firmware" page to update after connected to the internet, or you may update offline according to wiki.

X1 series/P1 series/
A1Mini/A1/H2 series/P2S



Scan for article

Aliases: 0500-0500-0001-000E, 0500-0500-0001-000F,
0500-0500-0001-0011, 0500-0500-0001-0012, 0500-0400-0001-0046,
0500-0400-0001-0047, 0500-0400-0001-0048, 0500-0400-0001-0044,
0501-0400-0001-0044, 0502-0400-0001-0044, 0503-0400-0001-0044,
0500-0500-0001-0010, 0501-0500-0001-0010, 0502-0500-0001-0010,
0503-0500-0001-0010, 0580-0500-0001-0010, 0581-0500-0001-0010,
0582-0500-0001-0010, 0583-0500-0001-0010, 0584-0500-0001-0010,
0585-0500-0001-0010, 0586-0500-0001-0010, 0587-0500-0001-0010,
0580-0400-0001-0045, 0581-0400-0001-0045, 0582-0400-0001-0045,
0583-0400-0001-0045, 0584-0400-0001-0045, 0585-0400-0001-0045,
0586-0400-0001-0045, 0587-0400-0001-0045

HMS 0500-0300-0002-0055: User information has expired, please log in again.

**X1 series/P1 series/
A1Mini/A1/H2 series**



Scan for article

HMS 0500-0400-0001-0001: Failed to download print job. Please check your network connection.

**X1 series/P1 series/H2
series**



Scan for article

HMS 0500-0400-0001-0002: Failed to report print state. Please check your network connection.

X1 series/P1 series/P2S



Scan for article

HMS 0500-0400-0001-0003: The content of print file is unreadable. Please resend the print job.

**X1 series/P1 series/H2
series/P2S**



Scan for article

HMS 0500-0400-0001-0004: The print file is unauthorized.

X1 series/P1 series/P2S



Scan for article

HMS 0500-0400-0001-0006: Failed to resume previous print.

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0500-0400-0002-0007: The bed temperature exceeds the filament's vitrification temperature, which may cause a nozzle clog.

X1 series/P1 series



Scan for article

HMS 0500-0500-0001-0007: MQTT Command verification failed, please update Studio or Handy.

X1 series/P1 series/A1 mini/A1/H2 series



Scan for article

HMS 0500-0500-0001-0014: AMS A certification failed. Please reconnect the cable or restart the printer.

Aliases: 0501-0500-0001-0014, 0502-0500-0001-0014, 0503-0500-0001-0014

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0580-0500-0001-0017: AMS-HT A certification failed. Please reconnect the cable or restart the printer.

Aliases: 0581-0500-0001-0017, 0582-0500-0001-0017,
0583-0500-0001-0017, 0584-0500-0001-0017, 0585-0500-0001-0017,
0586-0500-0001-0017, 0587-0500-0001-0017

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0580-0500-0001-0017: AMS-HT A certification failed. Please reconnect the cable or restart the printer.

Aliases: 0581-0500-0001-0017, 0582-0500-0001-0017,
0583-0500-0001-0017, 0584-0500-0001-0017, 0585-0500-0001-0017,
0586-0500-0001-0017, 0587-0500-0001-0017

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini



Scan for article

HMS 0700-0100-0001-0001: The AMS assist motor has slipped. The extrusion wheel may be worn down, or the filament may be too thin.

X1 series/P1 series



Scan for article

HMS 0700-0100-0001-0003: The AMS assist motor torque control is malfunctioning. The current sensor may be faulty.

X1 series/P1 series/P2S



Scan for article

HMS 0700-0100-0001-0004: The AMS assist motor speed control is malfunctioning. The speed sensor may be faulty.

X1 series/P1 series/P2S



Scan for article

HMS 0700-0100-0001-0005: AMS A The current sensor of assist motor may be faulty.

Aliases: 0701-0100-0001-0005, 0702-0100-0001-0005, 0703-0100-0001-0005, 0704-0100-0001-0005, 0705-0100-0001-0005, 0706-0100-0001-0005, 0707-0100-0001-0005, 1800-0100-0001-0005, 1801-0100-0001-0005, 1802-0100-0001-0005, 1803-0100-0001-0005, 1804-0100-0001-0005, 1805-0100-0001-0005, 1806-0100-0001-0005, 1807-0100-0001-0005

H2 series/X1 series/P1 series/P2 series/A1/A1Mini



Scan for article

HMS 0700-0100-0002-0002: The AMS assist motor is overloaded, The filament may be tangled or stuck.

Aliases: 0701-0100-0002-0002, 0702-0100-0002-0002, 0703-0100-0002-0002

X1 series/P1 series/P2S



Scan for article

HMS 0700-0100-0002-0007: AMS A The assist motor encoder wires are not connected. The assist motor connector may have poor contact.

Aliases: 0701-0100-0002-0007, 0702-0100-0002-0007, 0703-0100-0002-0007, 1800-0100-0002-0007, 1801-0100-0002-0007, 1802-0100-0002-0007, 1803-0100-0002-0007, 1804-0100-0002-0007, 1805-0100-0002-0007, 1806-0100-0002-0007, 1807-0100-0002-0007

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0700-0200-0001-0001: AMS filament speed and length error. The filament odometry may be faulty.

X1 series/P1 series/P2S



Scan for article

HMS 0700-1000-0001-0001: The AMS slot1 motor has slipped. The

X1 series/P1 series



Scan for article

HMS 0700-1000-0001-0003: The AMS slot1 motor torque control is malfunctioning. The current sensor may be faulty.

X1 series/P1 series



Scan for article

HMS 0700-1000-0002-0002: The AMS slot1 motor is overloaded. The filament may be tangled or stuck.

X1 series/P1 series



Scan for article

HMS 0700-2000-0001-0081: Failed to read the filament information from AMS A slot 1. The AMS main board may be malfunctioning.

Aliases: 0700-2100-0001-0081, 0700-2200-0001-0081, 0700-2300-0001-0081, 0701-2000-0001-0081, 0701-2100-0001-0081, 0701-2200-0001-0081, 0701-2300-0001-0081, 0702-2000-0001-0081, 0702-2100-0001-0081, 0702-2200-0001-0081, 0702-2300-0001-0081, 0703-2000-0001-0081, 0703-2100-0001-0081, 0703-2200-0001-0081, 0703-2300-0001-0081, 1800-2000-0001-0081, 1801-2000-0001-0081, 1802-2000-0001-0081, 1803-2000-0001-0081, 1804-2000-0001-0081, 1805-2000-0001-0081, 1806-2000-0001-0081, 1807-2000-0001-0081

X1 series/P1 series/P2S/
H2 series/A1/A1 mini/
AMS/AMS HT



Scan for article

HMS 0700-2000-0001-0083: Failed to read the filament information from AMS A slot 1. The RFID tag may be damaged

Aliases: 0700-2100-0001-0083, 0700-2200-0001-0083, 0700-2300-0001-0083, 0701-2000-0001-0083, 0701-2100-0001-0083, 0701-2200-0001-0083, 0701-2300-0001-0083, 0702-2000-0001-0083, 0702-2100-0001-0083, 0702-2200-0001-0083, 0702-2300-0001-0083, 0703-2000-0001-0083, 0703-2100-0001-0083, 0703-2200-0001-0083, 0703-2300-0001-0083, 1800-2000-0001-0083, 1801-2000-0001-0083, 1802-2000-0001-0083, 1803-2000-0001-0083, 1804-2000-0001-0083, 1805-2000-0001-0083, 1806-2000-0001-0083, 1807-2000-0001-0083

X1 series/P1 series/P2S/
H2 series/A1/A1 mini/
AMS/AMS HT



Scan for article

HMS 0700-2000-0001-0084: Failed to read the filament information from AMS A slot 1. The RFID tag may be damaged or positioned at the edge of the RFID detection device. Please remove 5cm filament and try again.

Aliases: 0700-2100-0001-0084, 0700-2200-0001-0084,
0700-2300-0001-0084, 0701-2000-0001-0084, 0701-2100-0001-0084,
0701-2200-0001-0084, 0701-2300-0001-0084, 0702-2000-0001-0084,
0702-2100-0001-0084, 0702-2200-0001-0084,
0702-2300-0001-0084, 0703-2000-0001-0084, 0703-2100-0001-0084,
0703-2200-0001-0084, 0703-2300-0001-0084, 1800-2000-0001-0084,
1801-2000-0001-0084, 1802-2000-0001-0084,
1803-2000-0001-0084, 1804-2000-0001-0084, 1805-2000-0001-0084,
1806-2000-0001-0084, 1807-2000-0001-0084

X1 series/P1 series/P2S/
H2 series/A1/A1 mini/
AMS/AMS HT



Scan for article

HMS 0700-2000-0001-0086: Failed to read the filament information from AMS A slot 1. The RFID tag cannot rotate due to a jam during the filament loading or unloading. Please pull out the filament and try again.

Aliases: 0700-2100-0001-0086, 0700-2200-0001-0086,
0700-2300-0001-0086, 0701-2000-0001-0086, 0701-2100-0001-0086,
0701-2200-0001-0086, 0701-2300-0001-0086, 0702-2000-0001-0086,
0702-2100-0001-0086, 0702-2200-0001-0086, 0702-2300-0001-0086

H2 series/X1 series/P1
series/P2S



Scan for article

HMS 0700-2000-0002-0001: AMS1 Slot 1 filament has run out.

Aliases: 0700-2100-0002-0001, 0700-2200-0002-0001, 0700-2300-0002-0001, 0701-2000-0002-0001, 0701-2100-0002-0001, 0701-2200-0002-0001, 0701-2300-0002-0001, 0702-2000-0002-0001, 0702-2100-0002-0001, 0702-2200-0002-0001, 0702-2300-0002-0001, 0703-2000-0002-0001, 0703-2100-0002-0001, 0703-2200-0002-0001, 0703-2300-0002-0001, 0704-2000-0002-0001, 0704-2100-0002-0001, 0704-2200-0002-0001, 0704-2300-0002-0001, 0705-2000-0002-0001, 0705-2100-0002-0001, 0705-2200-0002-0001, 0705-2300-0002-0001, 0706-2000-0002-0001, 0706-2100-0002-0001, 0706-2200-0002-0001, 0706-2300-0002-0001, 0707-2000-0002-0001, 0707-2100-0002-0001, 0707-2200-0002-0001, 0707-2300-0002-0001, 1800-2000-0002-0001, 1800-2100-0002-0001, 1800-2200-0002-0001, 1800-2300-0002-0001, 1801-2000-0002-0001, 1801-2100-0002-0001, 1801-2200-0002-0001, 1801-2300-0002-0001, 1802-2000-0002-0001, 1802-2100-0002-0001, 1802-2200-0002-0001, 1802-2300-0002-0001, 1803-2000-0002-0001, 1803-2100-0002-0001, 1803-2200-0002-0001, 1803-2300-0002-0001, 1804-2000-0002-0001, 1804-2100-0002-0001, 1804-2200-0002-0001, 1804-2300-0002-0001, 1805-2000-0002-0001, 1805-2100-0002-0001, 1805-2200-0002-0001, 1805-2300-0002-0001, 1806-2000-0002-0001, 1806-2100-0002-0001, 1806-2200-0002-0001, 1806-2300-0002-0001, 1807-2000-0002-0001, 1807-2100-0002-0001, 1807-2200-0002-0001, 1807-2300-0002-0001

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0002: The AMS Slot 1 is empty.

Aliases: 0700-2100-0002-0002, 0700-2200-0002-0002, 0700-2300-0002-0002, 0701-2000-0002-0002, 0701-2100-0002-0002, 0701-2200-0002-0002, 0701-2300-0002-0002, 0702-2000-0002-0002, 0702-2100-0002-0002, 0702-2200-0002-0002, 0702-2300-0002-0002, 0703-2000-0002-0002, 0703-2100-0002-0002, 0703-2200-0002-0002, 0703-2300-0002-0002, 0704-2000-0002-0002, 0704-2100-0002-0002, 0704-2200-0002-0002, 0704-2300-0002-0002, 0705-2000-0002-0002, 0705-2100-0002-0002, 0705-2200-0002-0002, 0705-2300-0002-0002, 0706-2000-0002-0002, 0706-2100-0002-0002, 0706-2200-0002-0002, 0706-2300-0002-0002, 0707-2000-0002-0002, 0707-2100-0002-0002, 0707-2200-0002-0002, 0707-2300-0002-0002, 1800-2000-0002-0002, 1800-2100-0002-0002, 1800-2200-0002-0002, 1800-2300-0002-0002, 1801-2000-0002-0002, 1801-2100-0002-0002, 1801-2200-0002-0002, 1801-2300-0002-0002, 1802-2000-0002-0002, 1802-2100-0002-0002, 1802-2200-0002-0002, 1802-2300-0002-0002, 1803-2000-0002-0002, 1803-2100-0002-0002, 1803-2200-0002-0002, 1803-2300-0002-0002, 1804-2000-0002-0002, 1804-2100-0002-0002, 1804-2200-0002-0002, 1804-2300-0002-0002, 1805-2000-0002-0002, 1805-2100-0002-0002, 1805-2200-0002-0002, 1805-2300-0002-0002, 1806-2000-0002-0002, 1806-2100-0002-0002, 1806-2200-0002-0002, 1806-2300-0002-0002, 1807-2000-0002-0002, 1807-2100-0002-0002, 1807-2200-0002-0002, 1807-2300-0002-0002

X1 series/P1 series/H2 series



Scan for article

HMS 0700-2000-0002-0003: The AMS A Slot 1 filament may be broken in AMS.

Aliases: 0700-2100-0002-0003, 0700-2200-0002-0003, 0700-2300-0002-0003, 0701-2000-0002-0003, 0701-2100-0002-0003, 0701-2200-0002-0003, 0701-2300-0002-0003, 0702-2000-0002-0003, 0702-2100-0002-0003, 0702-2200-0002-0003, 0702-2300-0002-0003, 0703-2000-0002-0003, 0703-2100-0002-0003, 0703-2200-0002-0003, 0703-2300-0002-0003, 0704-2000-0002-0003, 0704-2100-0002-0003, 0704-2200-0002-0003, 0704-2300-0002-0003, 0705-2000-0002-0003, 0705-2100-0002-0003, 0705-2200-0002-0003, 0705-2300-0002-0003, 0706-2000-0002-0003, 0706-2100-0002-0003, 0706-2200-0002-0003, 0706-2300-0002-0003, 0707-2000-0002-0003, 0707-2100-0002-0003, 0707-2200-0002-0003, 0707-2300-0002-0003, 1800-2000-0002-0003, 1800-2100-0002-0003, 1800-2200-0002-0003, 1800-2300-0002-0003, 1801-2000-0002-0003, 1801-2100-0002-0003, 1801-2200-0002-0003, 1801-2300-0002-0003, 1802-2000-0002-0003, 1802-2100-0002-0003, 1802-2200-0002-0003, 1802-2300-0002-0003, 1803-2000-0002-0003, 1803-2100-0002-0003, 1803-2200-0002-0003, 1803-2300-0002-0003, 1804-2000-0002-0003, 1804-2100-0002-0003, 1804-2200-0002-0003, 1804-2300-0002-0003, 1805-2000-0002-0003, 1805-2100-0002-0003, 1805-2200-0002-0003, 1805-2300-0002-0003

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0004: The AMS A Slot 1 filament may be broken in the toolhead.

Aliases: 0700-2100-0002-0004, 0700-2200-0002-0004, 0700-2300-0002-0004, 0701-2000-0002-0004, 0701-2100-0002-0004, 0701-2200-0002-0004, 0701-2300-0002-0004, 0702-2000-0002-0004, 0702-2100-0002-0004, 0702-2200-0002-0004, 0702-2300-0002-0004, 0703-2000-0002-0004, 0703-2100-0002-0004, 0703-2200-0002-0004, 0703-2300-0002-0004, 0704-2000-0002-0004, 0704-2100-0002-0004, 0704-2200-0002-0004, 0704-2300-0002-0004, 0705-2000-0002-0004, 0705-2100-0002-0004, 0705-2200-0002-0004, 0705-2300-0002-0004, 0706-2000-0002-0004, 0706-2100-0002-0004, 0706-2200-0002-0004, 0706-2300-0002-0004, 0707-2000-0002-0004, 0707-2100-0002-0004, 0707-2200-0002-0004, 0707-2300-0002-0004, 1800-2000-0002-0004, 1800-2100-0002-0004, 1800-2200-0002-0004, 1800-2300-0002-0004, 1801-2000-0002-0004, 1801-2100-0002-0004, 1801-2200-0002-0004, 1801-2300-0002-0004, 1802-2000-0002-0004, 1802-2100-0002-0004, 1802-2200-0002-0004, 1802-2300-0002-0004, 1803-2000-0002-0004, 1803-2100-0002-0004, 1803-2200-0002-0004, 1803-2300-0002-0004, 1804-2000-0002-0004, 1804-2100-0002-0004, 1804-2200-0002-0004, 1804-2300-0002-0004, 1805-2000-0002-0004, 1805-2100-0002-0004, 1805-2200-0002-0004, 1805-2300-0002-0004, 1806-2000-0002-0004, 1806-2100-0002-0004, 1806-2200-0002-0004, 1806-2300-0002-0004, 1807-2000-0002-0004, 1807-2100-0002-0004, 1807-2200-0002-0004, 1807-2300-0002-0004

X1 series/P1 series/H2 series



Scan for article

HMS 0700-2000-0002-0005: AMS A Slot 1 filament has run out, and purging the old filament went abnormally; please check whether the filament is stuck in the tool head.

Aliases: 0700-2100-0002-0005, 0700-2200-0002-0005, 0700-2300-0002-0005, 0701-2000-0002-0005, 0701-2100-0002-0005, 0701-2200-0002-0005, 0701-2300-0002-0005, 0702-2000-0002-0005, 0702-2100-0002-0005, 0702-2200-0002-0005, 0702-2300-0002-0005, 0703-2000-0002-0005, 0703-2100-0002-0005, 0703-2200-0002-0005, 0703-2300-0002-0005, 0704-2000-0002-0005, 0704-2100-0002-0005, 0704-2200-0002-0005, 0704-2300-0002-0005, 0705-2000-0002-0005, 0705-2100-0002-0005, 0705-2200-0002-0005, 0705-2300-0002-0005, 0706-2000-0002-0005, 0706-2100-0002-0005, 0706-2200-0002-0005, 0706-2300-0002-0005, 0707-2000-0002-0005, 0707-2100-0002-0005, 0707-2200-0002-0005, 0707-2300-0002-0005, 1800-2000-0002-0005, 1800-2100-0002-0005, 1800-2200-0002-0005, 1800-2300-0002-0005, 1801-2000-0002-0005, 1801-2100-0002-0005, 1801-2200-0002-0005, 1801-2300-0002-0005, 1802-2000-0002-0005, 1802-2100-0002-0005, 1802-2200-0002-0005, 1802-2300-0002-0005, 1803-2000-0002-0005, 1803-2100-0002-0005, 1803-2200-0002-0005, 1803-2300-0002-0005, 1804-2000-0002-0005, 1804-2100-0002-0005, 1804-2200-0002-0005, 1804-2300-0002-0005, 1805-2000-0002-0005, 1805-2100-0002-0005, 1805-2200-0002-0005, 1805-2300-0002-0005, 1806-2000-0002-0005, 1806-2100-0002-0005, 1806-2200-0002-0005, 1806-2300-0002-0005, 1807-2000-0002-0005, 1807-2100-0002-0005, 1807-2200-0002-0005, 1807-2300-0002-0005

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0006: PTFE tube detached during the feeding process. Please check if the PTFE tube is connected from AMS to extruder.

Aliases: 0700-2100-0002-0006, 0700-2200-0002-0006, 0700-2300-0002-0006, 0701-2000-0002-0006, 0701-2100-0002-0006, 0701-2200-0002-0006, 0701-2300-0002-0006, 0702-2000-0002-0006, 0702-2100-0002-0006, 0702-2200-0002-0006, 0702-2300-0002-0006, 0703-2000-0002-0006, 0703-2100-0002-0006, 0703-2200-0002-0006, 0703-2300-0002-0006, 0704-2000-0002-0006, 0704-2100-0002-0006, 0704-2200-0002-0006, 0704-2300-0002-0006, 0705-2000-0002-0006, 0705-2100-0002-0006, 0705-2200-0002-0006, 0705-2300-0002-0006, 0706-2000-0002-0006, 0706-2100-0002-0006, 0706-2200-0002-0006, 0706-2300-0002-0006, 0707-2000-0002-0006, 0707-2100-0002-0006, 0707-2200-0002-0006, 0707-2300-0002-0006, 1800-2000-0002-0006, 1800-2100-0002-0006, 1800-2200-0002-0006, 1800-2300-0002-0006, 1801-2000-0002-0006, 1801-2100-0002-0006, 1801-2200-0002-0006, 1801-2300-0002-0006, 1802-2000-0002-0006, 1802-2100-0002-0006, 1802-2200-0002-0006, 1802-2300-0002-0006, 1803-2000-0002-0006, 1803-2100-0002-0006, 1803-2200-0002-0006, 1803-2300-0002-0006, 1804-2000-0002-0006, 1804-2100-0002-0006, 1804-2200-0002-0006, 1804-2300-0002-0006, 1805-2000-0002-0006, 1805-2100-0002-0006, 1805-2200-0002-0006, 1805-2300-0002-0006, 1806-2000-0002-0006, 1806-2100-0002-0006, 1806-2200-0002-0006, 1806-2300-0002-0006, 1807-2000-0002-0006, 1807-2100-0002-0006, 1807-2200-0002-0006, 1807-2300-0002-0006

X1 series/P1 series/H2 series



Scan for article

HMS 0700-2000-0002-0010: AMS A slot 1 feeds filament out of AMS timeout.

Aliases: 0700-2100-0002-0010, 0700-2200-0002-0010, 0700-2300-0002-0010, 0701-2000-0002-0010, 0701-2100-0002-0010, 0701-2200-0002-0010, 0701-2300-0002-0010, 0702-2000-0002-0010, 0702-2100-0002-0010, 0702-2200-0002-0010, 0702-2300-0002-0010, 0703-2000-0002-0010, 0703-2100-0002-0010, 0703-2200-0002-0010, 0703-2300-0002-0010, 1800-2000-0002-0010, 1801-2000-0002-0010, 1802-2000-0002-0010, 1803-2000-0002-0010, 1804-2000-0002-0010, 1805-2000-0002-0010, 1806-2000-0002-0010, 1807-2000-0002-0010

X1 series/P1 series/P2S/H2 series/ A1/A1 mini



Scan for article

HMS 0700-2000-0002-0011: AMS A slot 1 pulls filament back to AMS timeout.

Aliases: 0700-2100-0002-0011, 0700-2200-0002-0011, 0700-2300-0002-0011, 0701-2000-0002-0011, 0701-2100-0002-0011, 0701-2200-0002-0011, 0701-2300-0002-0011, 0702-2000-0002-0011, 0702-2100-0002-0011, 0702-2200-0002-0011, 0702-2300-0002-0011, 0703-2000-0002-0011, 0703-2100-0002-0011, 0703-2200-0002-0011, 0703-2300-0002-0011, 0704-2000-0002-0011, 0704-2100-0002-0011, 0704-2200-0002-0011, 0704-2300-0002-0011, 0705-2000-0002-0011, 0705-2100-0002-0011, 0705-2200-0002-0011, 0705-2300-0002-0011, 0706-2000-0002-0011, 0706-2100-0002-0011, 0706-2200-0002-0011, 0706-2300-0002-0011, 0707-2000-0002-0011, 0707-2100-0002-0011, 0707-2200-0002-0011, 0707-2300-0002-0011, 1800-2000-0002-0011, 1800-2100-0002-0011, 1800-2200-0002-0011, 1800-2300-0002-0011, 1801-2000-0002-0011, 1801-2100-0002-0011, 1801-2200-0002-0011, 1801-2300-0002-0011, 1802-2000-0002-0011, 1802-2100-0002-0011, 1802-2200-0002-0011, 1802-2300-0002-0011, 1803-2000-0002-0011, 1803-2100-0002-0011, 1803-2200-0002-0011, 1803-2300-0002-0011, 1804-2000-0002-0011, 1804-2100-0002-0011, 1804-2200-0002-0011, 1804-2300-0002-0011, 1805-2000-0002-0011, 1805-2100-0002-0011, 1805-2200-0002-0011, 1805-2300-0002-0011, 1806-2000-0002-0011, 1806-2100-0002-0011, 1806-2200-0002-0011, 1806-2300-0002-0011, 1807-2000-0002-0011, 1807-2100-0002-0011, 1807-2200-0002-0011, 1807-2300-0002-0011

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0012: AMS A slot 1 feeder unit motor is stalled, cannot rotate the spool.

Aliases: 0700-2100-0002-0012, 0700-2200-0002-0012, 0700-2300-0002-0012, 0701-2000-0002-0012, 0701-2100-0002-0012, 0701-2200-0002-0012, 0701-2300-0002-0012, 0702-2000-0002-0012, 0702-2100-0002-0012, 0702-2200-0002-0012, 0702-2300-0002-0012, 0703-2000-0002-0012, 0703-2100-0002-0012, 0703-2200-0002-0012, 0703-2300-0002-0012, 0704-2000-0002-0012, 0704-2100-0002-0012, 0704-2200-0002-0012, 0704-2300-0002-0012, 0705-2000-0002-0012, 0705-2100-0002-0012, 0705-2200-0002-0012, 0705-2300-0002-0012, 0706-2000-0002-0012, 0706-2100-0002-0012, 0706-2200-0002-0012, 0706-2300-0002-0012, 0707-2000-0002-0012, 0707-2100-0002-0012, 0707-2200-0002-0012, 0707-2300-0002-0012, 1800-2000-0002-0012, 1800-2100-0002-0012, 1800-2200-0002-0012, 1800-2300-0002-0012, 1801-2000-0002-0012, 1801-2100-0002-0012, 1801-2200-0002-0012, 1801-2300-0002-0012, 1802-2000-0002-0012, 1802-2100-0002-0012, 1802-2200-0002-0012, 1802-2300-0002-0012, 1803-2000-0002-0012, 1803-2100-0002-0012, 1803-2200-0002-0012, 1803-2300-0002-0012, 1804-2000-0002-0012, 1804-2100-0002-0012, 1804-2200-0002-0012, 1804-2300-0002-0012, 1805-2000-0002-0012, 1805-2100-0002-0012, 1805-2200-0002-0012, 1805-2300-0002-0012, 1806-2000-0002-0012, 1806-2100-0002-0012, 1806-2200-0002-0012, 1806-2300-0002-0012, 1807-2000-0002-0012, 1807-2100-0002-0012, 1807-2200-0002-0012, 1807-2300-0002-0012

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0013: AMS A slot 1 feeder unit motor has no signal, which may be due to poor contact in the motor connector or a motor fault.

Aliases: 0700-2100-0002-0013, 0700-2200-0002-0013, 0700-2300-0002-0013, 0701-2000-0002-0013, 0701-2100-0002-0013, 0701-2200-0002-0013, 0701-2300-0002-0013, 0702-2000-0002-0013, 0702-2100-0002-0013, 0702-2200-0002-0013, 0702-2300-0002-0013, 0703-2000-0002-0013, 0703-2100-0002-0013, 0703-2200-0002-0013, 0703-2300-0002-0013, 0704-2000-0002-0013, 0704-2100-0002-0013, 0704-2200-0002-0013, 0704-2300-0002-0013, 0705-2000-0002-0013, 0705-2100-0002-0013, 0705-2200-0002-0013, 0705-2300-0002-0013, 0706-2000-0002-0013, 0706-2100-0002-0013, 0706-2200-0002-0013, 0706-2300-0002-0013, 0707-2000-0002-0013, 0707-2100-0002-0013, 0707-2200-0002-0013, 0707-2300-0002-0013, 1800-2000-0002-0013, 1800-2100-0002-0013, 1800-2200-0002-0013, 1800-2300-0002-0013, 1801-2000-0002-0013, 1801-2100-0002-0013, 1801-2200-0002-0013, 1801-2300-0002-0013, 1802-2000-0002-0013, 1802-2100-0002-0013, 1802-2200-0002-0013, 1802-2300-0002-0013, 1803-2000-0002-0013, 1803-2100-0002-0013, 1803-2200-0002-0013, 1803-2300-0002-0013, 1804-2000-0002-0013, 1804-2100-0002-0013, 1804-2200-0002-0013, 1804-2300-0002-0013, 1805-2000-0002-0013, 1805-2100-0002-0013, 1805-2200-0002-0013, 1805-2300-0002-0013, 1806-2000-0002-0013, 1806-2100-0002-0013, 1806-2200-0002-0013, 1806-2300-0002-0013, 1807-2000-0002-0013, 1807-2100-0002-0013, 1807-2200-0002-0013, 1807-2300-0002-0013

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0014: AMS A Slot 1 odometer no signal - possible poor odometer connector contact or odometer failure.

Aliases: 0700-2100-0002-0014, 0700-2200-0002-0014, 0700-2300-0002-0014, 0701-2000-0002-0014, 0701-2100-0002-0014, 0701-2200-0002-0014, 0701-2300-0002-0014, 0702-2000-0002-0014, 0702-2100-0002-0014, 0702-2200-0002-0014, 0702-2300-0002-0014, 0703-2000-0002-0014, 0703-2100-0002-0014, 0703-2200-0002-0014, 0703-2300-0002-0014, 0704-2000-0002-0014, 0704-2100-0002-0014, 0704-2200-0002-0014, 0704-2300-0002-0014, 0705-2000-0002-0014, 0705-2100-0002-0014, 0705-2200-0002-0014, 0705-2300-0002-0014, 0706-2000-0002-0014, 0706-2100-0002-0014, 0706-2200-0002-0014, 0706-2300-0002-0014, 0707-2000-0002-0014, 0707-2100-0002-0014, 0707-2200-0002-0014, 0707-2300-0002-0014, 1800-2000-0002-0014, 1800-2100-0002-0014, 1800-2200-0002-0014, 1800-2300-0002-0014, 1801-2000-0002-0014, 1801-2100-0002-0014, 1801-2200-0002-0014, 1801-2300-0002-0014, 1802-2000-0002-0014, 1802-2100-0002-0014, 1802-2200-0002-0014, 1802-2300-0002-0014, 1803-2000-0002-0014, 1803-2100-0002-0014, 1803-2200-0002-0014, 1803-2300-0002-0014, 1804-2000-0002-0014, 1804-2100-0002-0014, 1804-2200-0002-0014, 1804-2300-0002-0014, 1805-2000-0002-0014, 1805-2100-0002-0014, 1805-2200-0002-0014, 1805-2300-0002-0014, 1806-2000-0002-0014, 1806-2100-0002-0014, 1806-2200-0002-0014, 1806-2300-0002-0014, 1807-2000-0002-0014, 1807-2100-0002-0014, 1807-2200-0002-0014, 1807-2300-0002-0014

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0015: AMS A slot 1 filament status is abnormal, which may be due to a filament breakage inside the AMS.

Aliases: 0700-2100-0002-0015, 0700-2200-0002-0015, 0700-2300-0002-0015, 0701-2000-0002-0015, 0701-2100-0002-0015, 0701-2200-0002-0015, 0701-2300-0002-0015, 0702-2000-0002-0015, 0702-2100-0002-0015, 0702-2200-0002-0015, 0702-2300-0002-0015, 0703-2000-0002-0015, 0703-2100-0002-0015, 0703-2200-0002-0015, 0703-2300-0002-0015, 0704-2000-0002-0015, 0704-2100-0002-0015, 0704-2200-0002-0015, 0704-2300-0002-0015, 0705-2000-0002-0015, 0705-2100-0002-0015, 0705-2200-0002-0015, 0705-2300-0002-0015, 0706-2000-0002-0015, 0706-2100-0002-0015, 0706-2200-0002-0015, 0706-2300-0002-0015, 0707-2000-0002-0015, 0707-2100-0002-0015, 0707-2200-0002-0015, 0707-2300-0002-0015, 1800-2000-0002-0015, 1800-2100-0002-0015, 1800-2200-0002-0015, 1800-2300-0002-0015, 1801-2000-0002-0015, 1801-2100-0002-0015, 1801-2200-0002-0015, 1801-2300-0002-0015, 1802-2000-0002-0015, 1802-2100-0002-0015, 1802-2200-0002-0015, 1802-2300-0002-0015, 1803-2000-0002-0015, 1803-2100-0002-0015, 1803-2200-0002-0015, 1803-2300-0002-0015, 1804-2000-0002-0015, 1804-2100-0002-0015, 1804-2200-0002-0015, 1804-2300-0002-0015, 1805-2000-0002-0015, 1805-2100-0002-0015, 1805-2200-0002-0015, 1805-2300-0002-0015, 1806-2000-0002-0015, 1806-2100-0002-0015, 1806-2200-0002-0015, 1806-2300-0002-0015, 1807-2000-0002-0015, 1807-2100-0002-0015, 1807-2200-0002-0015, 1807-2300-0002-0015

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0016: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube between AMS and the printer.

Aliases: 0700-2100-0002-0016, 0700-2200-0002-0016, 0700-2300-0002-0016, 0701-2000-0002-0016, 0701-2100-0002-0016, 0701-2200-0002-0016, 0701-2300-0002-0016, 0702-2000-0002-0016, 0702-2100-0002-0016, 0702-2200-0002-0016, 0702-2300-0002-0016, 0703-2000-0002-0016, 0703-2100-0002-0016, 0703-2200-0002-0016, 0703-2300-0002-0016, 0704-2000-0002-0016, 0704-2100-0002-0016, 0704-2200-0002-0016, 0704-2300-0002-0016, 0705-2000-0002-0016, 0705-2100-0002-0016, 0705-2200-0002-0016, 0705-2300-0002-0016, 0706-2000-0002-0016, 0706-2100-0002-0016, 0706-2200-0002-0016, 0706-2300-0002-0016, 0707-2000-0002-0016, 0707-2100-0002-0016, 0707-2200-0002-0016, 0707-2300-0002-0016, 1800-2000-0002-0016, 1800-2100-0002-0016, 1800-2200-0002-0016, 1800-2300-0002-0016, 1801-2000-0002-0016, 1801-2100-0002-0016, 1801-2200-0002-0016, 1801-2300-0002-0016, 1802-2000-0002-0016, 1802-2100-0002-0016, 1802-2200-0002-0016, 1802-2300-0002-0016, 1803-2000-0002-0016, 1803-2100-0002-0016, 1803-2200-0002-0016, 1803-2300-0002-0016, 1804-2000-0002-0016, 1804-2100-0002-0016, 1804-2200-0002-0016, 1804-2300-0002-0016, 1805-2000-0002-0016, 1805-2100-0002-0016, 1805-2200-0002-0016, 1805-2300-0002-0016, 1806-2000-0002-0016, 1806-2100-0002-0016, 1806-2200-0002-0016, 1806-2300-0002-0016, 1807-2000-0002-0016, 1807-2100-0002-0016, 1807-2200-0002-0016, 1807-2300-0002-0016

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0017: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube between AMS and the printer.

Aliases: 0700-2100-0002-0017, 0700-2200-0002-0017, 0700-2300-0002-0017, 0701-2000-0002-0017, 0701-2100-0002-0017, 0701-2200-0002-0017, 0701-2300-0002-0017, 0702-2000-0002-0017, 0702-2100-0002-0017, 0702-2200-0002-0017, 0702-2300-0002-0017, 0703-2000-0002-0017, 0703-2100-0002-0017, 0703-2200-0002-0017, 0703-2300-0002-0017, 0704-2000-0002-0017, 0704-2100-0002-0017, 0704-2200-0002-0017, 0704-2300-0002-0017, 0705-2000-0002-0017, 0705-2100-0002-0017, 0705-2200-0002-0017, 0705-2300-0002-0017, 0706-2000-0002-0017, 0706-2100-0002-0017, 0706-2200-0002-0017, 0706-2300-0002-0017, 0707-2000-0002-0017, 0707-2100-0002-0017, 0707-2200-0002-0017, 0707-2300-0002-0017, 1800-2000-0002-0017, 1800-2100-0002-0017, 1800-2200-0002-0017, 1800-2300-0002-0017, 1801-2000-0002-0017, 1801-2100-0002-0017, 1801-2200-0002-0017, 1801-2300-0002-0017, 1802-2000-0002-0017, 1802-2100-0002-0017, 1802-2200-0002-0017, 1802-2300-0002-0017, 1803-2000-0002-0017, 1803-2100-0002-0017, 1803-2200-0002-0017, 1803-2300-0002-0017, 1804-2000-0002-0017, 1804-2100-0002-0017, 1804-2200-0002-0017, 1804-2300-0002-0017, 1805-2000-0002-0017, 1805-2100-0002-0017, 1805-2200-0002-0017, 1805-2300-0002-0017, 1806-2000-0002-0017, 1806-2100-0002-0017, 1806-2200-0002-0017, 1806-2300-0002-0017, 1807-2000-0002-0017, 1807-2100-0002-0017, 1807-2200-0002-0017, 1807-2300-0002-0017

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0018: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube near AMS.

Aliases: 0700-2100-0002-0018, 0700-2200-0002-0018, 0700-2300-0002-0018, 0701-2000-0002-0018, 0701-2100-0002-0018, 0701-2200-0002-0018, 0701-2300-0002-0018, 0702-2000-0002-0018, 0702-2100-0002-0018, 0702-2200-0002-0018, 0702-2300-0002-0018, 0703-2000-0002-0018, 0703-2100-0002-0018, 0703-2200-0002-0018, 0703-2300-0002-0018, 0704-2000-0002-0018, 0704-2100-0002-0018, 0704-2200-0002-0018, 0704-2300-0002-0018, 0705-2000-0002-0018, 0705-2100-0002-0018, 0705-2200-0002-0018, 0705-2300-0002-0018, 0706-2000-0002-0018, 0706-2100-0002-0018, 0706-2200-0002-0018, 0706-2300-0002-0018, 0707-2000-0002-0018, 0707-2100-0002-0018, 0707-2200-0002-0018, 0707-2300-0002-0018, 1800-2000-0002-0018, 1800-2100-0002-0018, 1800-2200-0002-0018, 1800-2300-0002-0018, 1801-2000-0002-0018, 1801-2100-0002-0018, 1801-2200-0002-0018, 1801-2300-0002-0018, 1802-2000-0002-0018, 1802-2100-0002-0018, 1802-2200-0002-0018, 1802-2300-0002-0018, 1803-2000-0002-0018, 1803-2100-0002-0018, 1803-2200-0002-0018, 1803-2300-0002-0018, 1804-2000-0002-0018, 1804-2100-0002-0018, 1804-2200-0002-0018, 1804-2300-0002-0018, 1805-2000-0002-0018, 1805-2100-0002-0018, 1805-2200-0002-0018, 1805-2300-0002-0018, 1806-2000-0002-0018, 1806-2100-0002-0018, 1806-2200-0002-0018, 1806-2300-0002-0018, 1807-2000-0002-0018, 1807-2100-0002-0018, 1807-2200-0002-0018, 1807-2300-0002-0018

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0019: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube between AMS and the filament buffer.

Aliases: 0700-2100-0002-0019, 0700-2200-0002-0019, 0700-2300-0002-0019, 0701-2000-0002-0019, 0701-2100-0002-0019, 0701-2200-0002-0019, 0701-2300-0002-0019, 0702-2000-0002-0019, 0702-2100-0002-0019, 0702-2200-0002-0019, 0702-2300-0002-0019, 0703-2000-0002-0019, 0703-2100-0002-0019, 0703-2200-0002-0019, 0703-2300-0002-0019, 0704-2000-0002-0019, 0704-2100-0002-0019, 0704-2200-0002-0019, 0704-2300-0002-0019, 0705-2000-0002-0019, 0705-2100-0002-0019, 0705-2200-0002-0019, 0705-2300-0002-0019, 0706-2000-0002-0019, 0706-2100-0002-0019, 0706-2200-0002-0019, 0706-2300-0002-0019, 0707-2000-0002-0019, 0707-2100-0002-0019, 0707-2200-0002-0019, 0707-2300-0002-0019, 1800-2000-0002-0019, 1800-2100-0002-0019, 1800-2200-0002-0019, 1800-2300-0002-0019, 1801-2000-0002-0019, 1801-2100-0002-0019, 1801-2200-0002-0019, 1801-2300-0002-0019, 1802-2000-0002-0019, 1802-2100-0002-0019, 1802-2200-0002-0019, 1802-2300-0002-0019, 1803-2000-0002-0019, 1803-2100-0002-0019, 1803-2200-0002-0019, 1803-2300-0002-0019, 1804-2000-0002-0019, 1804-2100-0002-0019, 1804-2200-0002-0019, 1804-2300-0002-0019, 1805-2000-0002-0019, 1805-2100-0002-0019, 1805-2200-0002-0019, 1805-2300-0002-0019, 1806-2000-0002-0019, 1806-2100-0002-0019, 1806-2200-0002-0019, 1806-2300-0002-0019, 1807-2000-0002-0019, 1807-2100-0002-0019, 1807-2200-0002-0019, 1807-2300-0002-0019

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0021: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube between the filament buffer and the toolhead.

Aliases: 0700-2100-0002-0021, 0700-2200-0002-0021, 0700-2300-0002-0021, 0701-2000-0002-0021, 0701-2100-0002-0021, 0701-2200-0002-0021, 0701-2300-0002-0021, 0702-2000-0002-0021, 0702-2100-0002-0021, 0702-2200-0002-0021, 0702-2300-0002-0021, 0703-2000-0002-0021, 0703-2100-0002-0021, 0703-2200-0002-0021, 0703-2300-0002-0021, 0704-2000-0002-0021, 0704-2100-0002-0021, 0704-2200-0002-0021, 0704-2300-0002-0021, 0705-2000-0002-0021, 0705-2100-0002-0021, 0705-2200-0002-0021, 0705-2300-0002-0021, 0706-2000-0002-0021, 0706-2100-0002-0021, 0706-2200-0002-0021, 0706-2300-0002-0021, 0707-2000-0002-0021, 0707-2100-0002-0021, 0707-2200-0002-0021, 0707-2300-0002-0021, 1800-2000-0002-0021, 1800-2100-0002-0021, 1800-2200-0002-0021, 1800-2300-0002-0021, 1801-2000-0002-0021, 1801-2100-0002-0021, 1801-2200-0002-0021, 1801-2300-0002-0021, 1802-2000-0002-0021, 1802-2100-0002-0021, 1802-2200-0002-0021, 1802-2300-0002-0021, 1803-2000-0002-0021, 1803-2100-0002-0021, 1803-2200-0002-0021, 1803-2300-0002-0021, 1804-2000-0002-0021, 1804-2100-0002-0021, 1804-2200-0002-0021, 1804-2300-0002-0021, 1805-2000-0002-0021, 1805-2100-0002-0021, 1805-2200-0002-0021, 1805-2300-0002-0021, 1806-2000-0002-0021, 1806-2100-0002-0021, 1806-2200-0002-0021, 1806-2300-0002-0021, 1807-2000-0002-0021, 1807-2100-0002-0021, 1807-2200-0002-0021, 1807-2300-0002-0021

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0022: AMS A Slot 1 assist motor is stalled due to excessive resistance in the tube near the toolhead.

Aliases: 0700-2100-0002-0022, 0700-2200-0002-0022, 0700-2300-0002-0022, 0701-2000-0002-0022, 0701-2100-0002-0022, 0701-2200-0002-0022, 0701-2300-0002-0022, 0702-2000-0002-0022, 0702-2100-0002-0022, 0702-2200-0002-0022, 0702-2300-0002-0022, 0703-2000-0002-0022, 0703-2100-0002-0022, 0703-2200-0002-0022, 0703-2300-0002-0022, 0704-2000-0002-0022, 0704-2100-0002-0022, 0704-2200-0002-0022, 0704-2300-0002-0022, 0705-2000-0002-0022, 0705-2100-0002-0022, 0705-2200-0002-0022, 0705-2300-0002-0022, 0706-2000-0002-0022, 0706-2100-0002-0022, 0706-2200-0002-0022, 0706-2300-0002-0022, 0707-2000-0002-0022, 0707-2100-0002-0022, 0707-2200-0002-0022, 0707-2300-0002-0022, 1800-2000-0002-0022, 1800-2100-0002-0022, 1800-2200-0002-0022, 1800-2300-0002-0022, 1801-2000-0002-0022, 1801-2100-0002-0022, 1801-2200-0002-0022, 1801-2300-0002-0022, 1802-2000-0002-0022, 1802-2100-0002-0022, 1802-2200-0002-0022, 1802-2300-0002-0022, 1803-2000-0002-0022, 1803-2100-0002-0022, 1803-2200-0002-0022, 1803-2300-0002-0022, 1804-2000-0002-0022, 1804-2100-0002-0022, 1804-2200-0002-0022, 1804-2300-0002-0022, 1805-2000-0002-0022, 1805-2100-0002-0022, 1805-2200-0002-0022, 1805-2300-0002-0022, 1806-2000-0002-0022, 1806-2100-0002-0022, 1806-2200-0002-0022, 1806-2300-0002-0022, 1807-2000-0002-0022, 1807-2100-0002-0022, 1807-2200-0002-0022, 1807-2300-0002-0022

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0002-0023: AMS A slot 1 the tube inside the AMS is broken, or feed-out hall sensor is faulty and cannot detect the filament.

Aliases: 0700-2100-0002-0023, 0700-2200-0002-0023, 0700-2300-0002-0023, 0701-2000-0002-0023, 0701-2100-0002-0023, 0701-2200-0002-0023, 0701-2300-0002-0023, 0702-2000-0002-0023, 0702-2100-0002-0023, 0702-2200-0002-0023, 0702-2300-0002-0023, 0703-2000-0002-0023, 0703-2100-0002-0023, 0703-2200-0002-0023, 0703-2300-0002-0023, 1800-2000-0002-0023, 1801-2000-0002-0023, 1802-2000-0002-0023, 1803-2000-0002-0023, 1804-2000-0002-0023, 1805-2000-0002-0023, 1806-2000-0002-0023, 1807-2000-0002-0023

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0700-2000-0002-0024: AMS A Slot 1 assist motor is stalledŸ failed to rotate the filament spool when pulling filament back to AMS.

Aliases: 0700-2100-0002-0024, 0700-2200-0002-0024, 0700-2300-0002-0024, 0701-2000-0002-0024, 0701-2100-0002-0024, 0701-2200-0002-0024, 0701-2300-0002-0024, 0702-2000-0002-0024, 0702-2100-0002-0024, 0702-2200-0002-0024, 0702-2300-0002-0024, 0703-2000-0002-0024, 0703-2100-0002-0024, 0703-2200-0002-0024, 0703-2300-0002-0024, 0704-2000-0002-0024, 0704-2100-0002-0024, 0704-2200-0002-0024, 0704-2300-0002-0024, 0705-2000-0002-0024, 0705-2100-0002-0024, 0705-2200-0002-0024, 0705-2300-0002-0024, 0706-2000-0002-0024, 0706-2100-0002-0024, 0706-2200-0002-0024, 0706-2300-0002-0024, 0707-2000-0002-0024, 0707-2100-0002-0024, 0707-2200-0002-0024, 0707-2300-0002-0024, 1800-2000-0002-0024, 1800-2100-0002-0024, 1800-2200-0002-0024, 1800-2300-0002-0024, 1801-2000-0002-0024, 1801-2100-0002-0024, 1801-2200-0002-0024, 1801-2300-0002-0024, 1802-2000-0002-0024, 1802-2100-0002-0024, 1802-2200-0002-0024, 1802-2300-0002-0024, 1803-2000-0002-0024, 1803-2100-0002-0024, 1803-2200-0002-0024, 1803-2300-0002-0024, 1804-2000-0002-0024, 1804-2100-0002-0024, 1804-2200-0002-0024, 1804-2300-0002-0024, 1805-2000-0002-0024, 1805-2100-0002-0024, 1805-2200-0002-0024, 1805-2300-0002-0024, 1806-2000-0002-0024, 1806-2100-0002-0024, 1806-2200-0002-0024, 1806-2300-0002-0024, 1807-2000-0002-0024, 1807-2100-0002-0024, 1807-2200-0002-0024, 1807-2300-0002-0024

X1 Series/P1 Series/H2 series



Scan for article

HMS 0700-2000-0002-0025: AMS A Slot 1 feed resistance is too high. Please reduce the feed resistance, decrease the rotation resistance of the spool, and avoid having the filament tube too long and excessively bent.

Aliases: 0700-2100-0002-0025, 0700-2200-0002-0025, 0700-2300-0002-0025, 0701-2000-0002-0025, 0701-2100-0002-0025, 0701-2200-0002-0025, 0701-2300-0002-0025, 0702-2000-0002-0025, 0702-2100-0002-0025, 0702-2200-0002-0025, 0702-2300-0002-0025, 0703-2000-0002-0025, 0703-2100-0002-0025, 0703-2200-0002-0025, 0703-2300-0002-0025, 0704-2000-0002-0025, 0704-2100-0002-0025, 0704-2200-0002-0025, 0704-2300-0002-0025, 0705-2000-0002-0025, 0705-2100-0002-0025, 0705-2200-0002-0025, 0705-2300-0002-0025, 0706-2000-0002-0025, 0706-2100-0002-0025, 0706-2200-0002-0025, 0706-2300-0002-0025, 0707-2000-0002-0025, 0707-2100-0002-0025, 0707-2200-0002-0025, 0707-2300-0002-0025, 1800-2000-0002-0025, 1800-2100-0002-0025, 1800-2200-0002-0025, 1800-2300-0002-0025, 1801-2000-0002-0025, 1801-2100-0002-0025, 1801-2200-0002-0025, 1801-2300-0002-0025, 1802-2000-0002-0025, 1802-2100-0002-0025, 1802-2200-0002-0025, 1802-2300-0002-0025, 1803-2000-0002-0025, 1803-2100-0002-0025, 1803-2200-0002-0025, 1803-2300-0002-0025, 1804-2000-0002-0025, 1804-2100-0002-0025, 1804-2200-0002-0025, 1804-2300-0002-0025, 1805-2000-0002-0025, 1805-2100-0002-0025, 1805-2200-0002-0025, 1805-2300-0002-0025, 1806-2000-0002-0025, 1806-2100-0002-0025, 1806-2200-0002-0025, 1806-2300-0002-0025, 1807-2000-0002-0025, 1807-2100-0002-0025, 1807-2200-0002-0025, 1807-2300-0002-0025

X1 Series/P1 Series/H2 series/P2S



Scan for article

HMS 0700-2000-0003-0001: AMS1 Slot1 filament has run out. Please wait while old filament is purged.

Aliases: 0700-2100-0003-0001, 0700-2200-0003-0001, 0700-2300-0003-0001, 0701-2000-0003-0001, 0701-2100-0003-0001, 0701-2200-0003-0001, 0701-2300-0003-0001, 0702-2000-0003-0001, 0702-2100-0003-0001, 0702-2200-0003-0001, 0702-2300-0003-0001, 0703-2000-0003-0001, 0703-2100-0003-0001, 0703-2200-0003-0001, 0703-2300-0003-0001

X1 series/P1 series



Scan for article

HMS 0700-2000-0003-0002: AMS1 Slot1 filament has run out and automatically switched to the slot with the same filament.

Aliases: 0700-2100-0003-0002, 0700-2200-0003-0002, 0700-2300-0003-0002, 0701-2000-0003-0002, 0701-2100-0003-0002, 0701-2200-0003-0002, 0701-2300-0003-0002, 0702-2000-0003-0002, 0702-2100-0003-0002, 0702-2200-0003-0002, 0702-2300-0003-0002, 0703-2000-0003-0002, 0703-2100-0003-0002, 0703-2200-0003-0002, 0703-2300-0003-0002

X1 series/P1 series



Scan for article

HMS 0700-4000-0002-0001: The filament buffer signal lost, the cable or position sensor may be malfunctioning.

Aliases: 0701-4000-0002-0001, 0702-4000-0002-0001, 0703-4000-0002-0001, 1800-4000-0002-0001, 1801-4000-0002-0001, 1802-4000-0002-0001, 1803-4000-0002-0001, 1804-4000-0002-0001, 1805-4000-0002-0001, 1806-4000-0002-0001, 1807-4000-0002-0001

X1 series/P1 series



Scan for article

HMS 0700-4000-0002-0002: The filament buffer position signal error,the position sensor may be malfunctioning.

X1 series/P1 series



Scan for article

HMS 0700-4000-0002-0003: The AMS Hub communication is abnormal,the cable may be not well connected.

X1 series/P1 series



Scan for article

HMS 0700-4000-0002-0004: The filament buffer signal is abnormal,the spring may be stuck or the filament may be tangle.

X1 series/P1 series



Scan for article

HMS 0700-4500-0002-0001: The filament cutter sensor is malfunctioning. The sensor may be disconnected or damaged.

X1 series/P1 series



Scan for article

HMS 0700-4500-0002-0002: The filament cutter's cutting distance is too large. The XY motor may lose steps.

X1 series/P1 series



Scan for article

HMS 0700-4500-0002-0003: The filament cutter handle has not been released. The handle or blade may be jammed, or there could be an issue with the filament sensor connection.

Aliases: 1200-4500-0002-0003

X1 series/P1 series



Scan for article

HMS 0700-5000-0002-0001: AMS A communication is abnormal; please check the connection cable.

Aliases: 0701-5000-0002-0001, 0702-5000-0002-0001, 0703-5000-0002-0001, 1800-5000-0002-0001, 1801-5000-0002-0001, 1802-5000-0002-0001, 1803-5000-0002-0001, 1804-5000-0002-0001, 1805-5000-0002-0001, 1806-5000-0002-0001, 1807-5000-0002-0001, 1200-5000-0002-0001, 1201-5000-0002-0001, 1202-5000-0002-0001, 1203-5000-0002-0001

X1 series/P1 series/H2 Series/A1/A1 mini



Scan for article

HMS 0700-5100-0003-0001: The AMS is disabled; please load filament from spool holder.

X1 series/P1 series



Scan for article

HMS 0700-6000-0002-0001: The AMS1 slot 1 is overloaded. The filament may be tangled or the spool may be stuck.

Aliases: 0700-7000-0002-0001, 0700-7100-0002-0001, 0700-7200-0002-0001, 0700-7300-0002-0001, 0701-7000-0002-0001, 0701-7100-0002-0001, 0701-7200-0002-0001, 0701-7300-0002-0001, 0702-7000-0002-0001, 0702-7100-0002-0001, 0702-7200-0002-0001, 0702-7300-0002-0001, 0703-7000-0002-0001, 0703-7100-0002-0001, 0703-7200-0002-0001, 0703-7300-0002-0001, 0704-7000-0002-0001, 0704-7100-0002-0001, 0704-7200-0002-0001, 0705-7000-0002-0001, 0705-7100-0002-0001, 0705-7200-0002-0001, 0705-7300-0002-0001, 0706-7000-0002-0001, 0706-7100-0002-0001, 0706-7200-0002-0001, 0706-7300-0002-0001, 0707-7000-0002-0001, 0707-7100-0002-0001, 0707-7200-0002-0001, 0707-7300-0002-0001, 1800-7000-0002-0001, 1800-7100-0002-0001, 1800-7200-0002-0001, 1800-7300-0002-0001, 1801-7000-0002-0001, 1801-7100-0002-0001, 1801-7200-0002-0001, 1801-7300-0002-0001, 1802-7000-0002-0001, 1802-7100-0002-0001, 1802-7200-0002-0001, 1802-7300-0002-0001, 1803-7000-0002-0001, 1803-7100-0002-0001, 1803-7200-0002-0001, 1803-7300-0002-0001, 1804-7000-0002-0001, 1804-7100-0002-0001, 1804-7200-0002-0001, 1804-7300-0002-0001, 1805-7000-0002-0001, 1805-7100-0002-0001, 1805-7200-0002-0001, 1805-7300-0002-0001, 1806-7000-0002-0001, 1806-7100-0002-0001, 1806-7200-0002-0001, 1806-7300-0002-0001, 1807-7000-0002-0001, 1807-7100-0002-0001, 1807-7200-0002-0001, 1807-7300-0002-0001

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0700-7000-0002-0001: Failed to pull out the filament from the extruder. Please check whether the extruder is clogged or whether the filament is broken inside the extruder.

Aliases: 0701-7000-0002-0001, 0702-7000-0002-0001, 0703-7000-0002-0001

X1 series/P1 series



Scan for article

HMS 0700-7000-0002-0002: Failed to feed the filament into the toolhead. Please check whether the filament or the spool is stuck.

Aliases: 0700-7100-0002-0002, 0700-7200-0002-0002, 0700-7300-0002-0002, 0701-7000-0002-0002, 0701-7100-0002-0002, 0701-7200-0002-0002, 0701-7300-0002-0002, 0702-7000-0002-0002, 0702-7100-0002-0002, 0702-7200-0002-0002, 0702-7300-0002-0002, 0703-7000-0002-0002, 0703-7100-0002-0002, 0703-7200-0002-0002, 0703-7300-0002-0002, 0704-7000-0002-0002, 0704-7100-0002-0002, 0704-7200-0002-0002, 0705-7000-0002-0002, 0705-7100-0002-0002, 0705-7200-0002-0002, 0705-7300-0002-0002, 0706-7000-0002-0002, 0706-7100-0002-0002, 0706-7200-0002-0002, 0706-7300-0002-0002, 0707-7000-0002-0002, 0707-7100-0002-0002, 0707-7200-0002-0002, 0707-7300-0002-0002, 1800-7000-0002-0002, 1800-7100-0002-0002, 1800-7200-0002-0002, 1800-7300-0002-0002, 1801-7000-0002-0002, 1801-7100-0002-0002, 1801-7200-0002-0002, 1801-7300-0002-0002, 1802-7000-0002-0002, 1802-7100-0002-0002, 1802-7200-0002-0002, 1802-7300-0002-0002, 1803-7000-0002-0002, 1803-7100-0002-0002, 1803-7200-0002-0002, 1803-7300-0002-0002, 1805-7000-0002-0002, 1805-7100-0002-0002, 1805-7200-0002-0002, 1805-7300-0002-0002, 1806-7000-0002-0002, 1806-7100-0002-0002, 1806-7200-0002-0002, 1806-7300-0002-0002, 1807-7000-0002-0002, 1807-7100-0002-0002, 1807-7200-0002-0002, 1807-7300-0002-0002

X1 series/P1 series/H2 series/P2S



Scan for article

HMS 0700-7000-0002-0003: Failed to extrude the filament. Please check if the extruder or nozzle clogged.

Aliases: 0701-7000-0002-0003, 0702-7000-0002-0003, 0703-7000-0002-0003, 0704-7000-0002-0003, 0705-7000-0002-0003, 0706-7000-0002-0003, 0707-7000-0002-0003, 1800-7000-0002-0003, 1801-7000-0002-0003, 1802-7000-0002-0003, 1803-7000-0002-0003, 1804-7000-0002-0003, 1805-7000-0002-0003, 1806-7000-0002-0003, 1807-7000-0002-0003

X1 series/P1 series/H2 series



Scan for article

HMS 0700-7000-0002-0004: Failed to pull back the filament from the toolhead to AMS. Please check whether the filament or the spool is stuck.

Aliases: 0700-7100-0002-0004,0700-7200-0002-0004, 0700-7300-0002-0004, 0701-7000-0002-0004, 0701-7100-0002-0004, 0701-7200-0002-0004, 0701-7300-0002-0004, 0702-7000-0002-0004, 0702-7100-0002-0004, 0702-7200-0002-0004, 0702-7300-0002-0004, 0703-7000-0002-0004, 0703-7100-0002-0004, 0703-7200-0002-0004, 0703-7300-0002-0004, 0704-7000-0002-0004, 0704-7100-0002-0004, 0704-7200-0002-0004, 0704-7300-0002-0004, 0705-7000-0002-0004, 0705-7100-0002-0004, 0705-7200-0002-0004, 0705-7300-0002-0004, 0706-7000-0002-0004, 0706-7100-0002-0004, 0706-7200-0002-0004, 0706-7300-0002-0004, 0707-7000-0002-0004, 0707-7100-0002-0004, 0707-7200-0002-0004, 0707-7300-0002-0004, 1800-7000-0002-0004, 1800-7100-0002-0004, 1800-7200-0002-0004, 1800-7300-0002-0004, 1801-7000-0002-0004, 1801-7100-0002-0004, 1801-7200-0002-0004, 1801-7300-0002-0004, 1802-7000-0002-0004, 1802-7100-0002-0004, 1802-7200-0002-0004, 1802-7300-0002-0004, 1803-7000-0002-0004, 1803-7100-0002-0004, 1803-7200-0002-0004, 1803-7300-0002-0004, 1804-7000-0002-0004, 1804-7100-0002-0004, 1804-7200-0002-0004, 1804-7300-0002-0004, 1805-7000-0002-0004, 1805-7100-0002-0004, 1805-7200-0002-0004, 1805-7300-0002-0004, 1806-7000-0002-0004, 1806-7100-0002-0004, 1806-7200-0002-0004, 1806-7300-0002-0004, 1807-7000-0002-0004, 1807-7100-0002-0004, 1807-7200-0002-0004, 1807-7300-0002-0004

X1 series/P1 series/H2 series



Scan for article

HMS 0700-7000-0002-0005: Failed to feed the filament outside the AMS. Please clip the end of the filament flat and check to see if the spool is stuck.

Aliases: 0700-7100-0002-0005,0700-7200-0002-0005, 0700-7300-0002-0005, 0701-7000-0002-0005, 0701-7100-0002-0005, 0701-7200-0002-0005, 0701-7300-0002-0005, 0702-7000-0002-0005, 0702-7100-0002-0005, 0702-7200-0002-0005, 0702-7300-0002-0005, 0703-7000-0002-0005, 0703-7100-0002-0005, 0703-7200-0002-0005, 0703-7300-0002-0005, 0704-7000-0002-0005, 0704-7100-0002-0005, 0704-7200-0002-0005, 0704-7300-0002-0005, 0705-7000-0002-0005, 0705-7100-0002-0005, 0705-7200-0002-0005, 0705-7300-0002-0005, 0706-7000-0002-0005, 0706-7100-0002-0005, 0706-7200-0002-0005, 0706-7300-0002-0005, 0707-7000-0002-0005, 0707-7100-0002-0005, 0707-7200-0002-0005, 0707-7300-0002-0005, 1800-7000-0002-0005, 1800-7100-0002-0005, 1800-7200-0002-0005, 1800-7300-0002-0005, 1801-7000-0002-0005, 1801-7100-0002-0005, 1801-7200-0002-0005, 1801-7300-0002-0005, 1802-7000-0002-0005, 1802-7100-0002-0005, 1802-7200-0002-0005, 1802-7300-0002-0005, 1803-7000-0002-0005, 1803-7100-0002-0005, 1803-7200-0002-0005, 1803-7300-0002-0005, 1804-7000-0002-0005, 1804-7100-0002-0005, 1804-7200-0002-0005, 1804-7300-0002-0005, 1805-7000-0002-0005, 1805-7100-0002-0005, 1805-7200-0002-0005, 1805-7300-0002-0005, 1806-7000-0002-0005, 1806-7100-0002-0005, 1806-7200-0002-0005, 1806-7300-0002-0005, 1807-7000-0002-0005, 1807-7100-0002-0005, 1807-7200-0002-0005, 1807-7300-0002-0005

X1 series/P1 series/H2 series



Scan for article

HMS 0700-7000-0002-0007: AMS filament ran out. Please put a new filament into AMS and click the "Retry" button.

Aliases: 0701-7000-0002-0007, 0702-7000-0002-0007 0703-7000-0002-0007

X1 series/P1 series



Scan for article

HMS 0700-7000-0002-0008: Failed to get AMS mapping table; please click "Resume" to retry.

Aliases: 0701-7000-0002-0008, 0702-7000-0002-0008, 0703-7000-0002-0008, 0704-7000-0002-0008, 0705-7000-0002-0008, 0706-7000-0002-0008, 0707-7000-0002-0008, 1800-7000-0002-0008, 1801-7000-0002-0008, 1802-7000-0002-0008, 1803-7000-0002-0008, 1804-7000-0002-0008, 1805-7000-0002-0008, 1806-7000-0002-0008, 1807-7000-0002-0008, 07FE-7000-0002-0008, 07FF-7000-0002-0008, 18FE-7000-0002-0008, 18FF-7000-0002-0008

X1 series/P1 series/H2 series



Scan for article

HMS 0700-8000-0001-0001: AMS A Heater 1 Current Sensor Abnormal.

Aliases: 0700-8100-0001-0001, 0701-8000-0001-0001, 0701-8100-0001-0001, 0702-8000-0001-0001, 0702-8100-0001-0001, 0703-8000-0001-0001, 0703-8100-0001-0001, 1800-8000-0001-0001, 1801-8000-0001-0001, 1802-8000-0001-0001, 1803-8000-0001-0001, 1804-8000-0001-0001, 1805-8000-0001-0001, 1806-8000-0001-0001, 1807-8000-0001-0001

X1 series/P1 series/P2S/H2 series/ A1/A1 mini/AMS 2 Pro/AMS HT<



Scan for article

HMS 0700-8000-0001-0002: AMS A Heater 1 is offline, possibly due to a loose connector.

Aliases: 0700-8100-0001-0002, 0701-8000-0001-0002, 0701-8100-0001-0002, 0702-8000-0001-0002, 0702-8100-0001-0002, 0703-8000-0001-0002, 0703-8100-0001-0002, 1800-8000-0001-0002, 1801-8000-0001-0002, 1802-8000-0001-0002, 1803-8000-0001-0002, 1804-8000-0001-0002, 1805-8000-0001-0002, 1806-8000-0001-0002, 1807-8000-0001-0002

X1 series/P1 series/P2S/H2 series/ A1/A1 mini/AMS 2 Pro/AMS HT<



Scan for article

HMS 0700-8000-0001-0003: AMS Heater A short circuit, possibly caused by wiring short or heater damage.

Aliases: 0700-8100-0001-0003, 0701-8000-0001-0003, 0701-8100-0001-0003, 0702-8000-0001-0003, 0702-8100-0001-0003, 0703-8000-0001-0003, 0703-8100-0001-0003, 1800-8000-0001-0003, 1801-8000-0001-0003, 1802-8000-0001-0003, 1803-8000-0001-0003, 1804-8000-0001-0003, 1805-8000-0001-0003, 1806-8000-0001-0003, 1807-8000-0001-0003

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini/
AMS 2 Pro/AMS HT



Scan for article

HMS 0700-8000-0001-0004: AMS A heater 1 abnormal heating.

Aliases: 0700-8100-0001-0004, 0701-8000-0001-0004, 0701-8100-0001-0004, 0702-8000-0001-0004, 0702-8100-0001-0004, 0703-8000-0001-0004, 0703-8100-0001-0004, 1800-8000-0001-0004, 1801-8000-0001-0004, 1802-8000-0001-0004, 1803-8000-0001-0004, 1804-8000-0001-0004, 1805-8000-0001-0004, 1806-8000-0001-0004, 1807-8000-0001-0004

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini/
AMS 2 Pro



Scan for article

HMS 0700-9000-0001-0003: AMS A The exhaust valve 1 is not connected, which may be due to poor connector contact.

Aliases: 0700-9100-0001-0003, 0701-9000-0001-0003, 0701-9100-0001-0003, 0702-9000-0001-0003, 0702-9100-0001-0003, 0703-9000-0001-0003, 0703-9100-0001-0003, 0704-9000-0001-0003, 0704-9100-0001-0003, 0705-9000-0001-0003, 0705-9100-0001-0003, 0706-9000-0001-0003, 0706-9100-0001-0003, 0707-9000-0001-0003, 0707-9100-0001-0003, 1800-9000-0001-0003, 1801-9000-0001-0003, 1802-9000-0001-0003, 1803-9000-0001-0003, 1804-9000-0001-0003, 1805-9000-0001-0003, 1806-9000-0001-0003, 1807-9000-0001-0003

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0700-9000-0002-0001: AMS A The operation of the exhaust valve 1 is abnormal, which may be due to excessive resistance.

Aliases: 0700-9100-0002-0001, 0701-9000-0002-0001, 0701-9100-0002-0001, 0702-9000-0002-0001, 0702-9100-0002-0001, 0703-9000-0002-0001, 0703-9100-0002-0001, 0704-9000-0002-0001, 0704-9100-0002-0001, 0705-9000-0002-0001, 0705-9100-0002-0001, 0706-9000-0002-0001, 0706-9100-0002-0001, 0707-9000-0002-0001, 0707-9100-0002-0001, 1800-9000-0002-0001, 1801-9000-0002-0001, 1802-9000-0002-0001, 1803-9000-0002-0001, 1804-9000-0002-0001, 1805-9000-0002-0001, 1806-9000-0002-0001, 1807-9000-0002-0001

X1 series/P1 series/P2S/
H2 series/A1/A1 mini/
AMS/AMS HT



Scan for article

HMS 0700-9200-0001-0001: AMS A The cooling fan of heater 1 is blocked, which may be due to the fan being stuck.

Aliases: 0700-9200-0001-0001ÿ 0700-9300-0001-0001ÿ 0701-9200-0001-0001ÿ 0701-9300-0001-0001ÿ 0702-9200-0001-0001ÿ 0702-9300-0001-0001ÿ 0703-9200-0001-0001ÿ 0703-9300-0001-0001ÿ 1800-9200-0001-0001ÿ 1801-9200-0001-0001ÿ 1802-9200-0001-0001ÿ 1803-9200-0001-0001ÿ 1804-9200-0001-0001ÿ 1805-9200-0001-0001ÿ 1806-9200-0001-0001ÿ 1807-9200-0001-0001

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini



Scan for article

HMS 0700-9200-0002-0002: AMS A Heater 1 cooling fan speed is low, possibly due to excessive resistance.

Aliases: 0700-9300-0002-0002, 0701-9200-0002-0002, 0701-9300-0002-0002, 0702-9200-0002-0002, 0702-9300-0002-0002, 0703-9200-0002-0002, 0703-9300-0002-0002, 1800-9200-0002-0002, 1801-9200-0002-0002, 1802-9200-0002-0002, 1803-9200-0002-0002, 1804-9200-0002-0002, 1805-9200-0002-0002, 1806-9200-0002-0002, 1807-9200-0002-0002

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini/
AMS 2 Pro/AMS HT



Scan for article

HMS 0700-9200-0002-0003: The AMS A heater 1 cooling fan cannot start because the power adapter is not connected.

Aliases: 0700-9200-0002-0003,0700-9300-0002-0003,0701-9200-0002-0003,0701-9300-0002-0003,0702-9200-0002-0003,0702-9300-0002-0003,0703-9200-0002-0003,0703-9300-0002-0003,1800-9200-0002-0003,1801-9200-0002-0003,1802-9200-0002-0003,1803-9200-0002-0003,1804-9200-0002-0003,1805-9200-0002-0003,1806-9200-0002-0003,1807-9200-0002-0003

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0700-9400-0001-0001: AMS A The temperature sensor of heater 1 is malfunctioning, which may be due to poor connector contact.

Aliases: 0700-9500-0001-0001, 0701-9400-0001-0001, 0701-9500-0001-0001, 0702-9400-0001-0001, 0702-9500-0001-0001, 0703-9400-0001-0001, 0703-9500-0001-0001, 1800-9400-0001-0001, 1801-9400-0001-0001, 1802-9400-0001-0001, 1803-9400-0001-0001, 1804-9400-0001-0001, 1805-9400-0001-0001, 1806-9400-0001-0001, 1807-9400-0001-0001

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 0700-9600-0001-0001: AMS A drying may be experiencing thermal runaway. Please power off the AMS immediately.

Aliases: 0701-9600-0001-0001, 0702-9600-0001-0001, 0703-9600-0001-0001, 0704-9600-0001-0001, 0705-9600-0001-0001, 0706-9600-0001-0001, 0707-9600-0001-0001, 1800-9600-0001-0001, 1801-9600-0001-0001, 1802-9600-0001-0001, 1803-9600-0001-0001, 1804-9600-0001-0001, 1805-9600-0001-0001, 1806-9600-0001-0001, 1807-9600-0001-0001

X1 series/P1 series/P2S/
H2 series/A1/A1 mini/
AMS 2 Pro/AMS HT



Scan for article

HMS 0700-9600-0001-0003: :AMS A Unable to start drying; please pull out the filament from filament hub and try again.

Aliases: 0701-9600-0001-0003, 0702-9600-0001-0003, 0703-9600-0001-0003, 0704-9600-0001-0003, 0705-9600-0001-0003, 0706-9600-0001-0003, 0707-9600-0001-0003, 1800-9600-0001-0003, 1801-9600-0001-0003, 1802-9600-0001-0003, 1803-9600-0001-0003, 1804-9600-0001-0003, 1805-9600-0001-0003, 1806-9600-0001-0003, 1807-9600-0001-0003

H2 series/X1 series/P1
series/P2S



Scan for article

HMS 0700-9600-0002-0002: The ambient temperature of the AMS is too low, which may affect the drying performance.

Aliases: 0701-9600-0002-0002, 0702-9600-0002-0002, 0703-9600-0002-0002, 0704-9600-0002-0002, 0705-9600-0002-0002, 0706-9600-0002-0002, 0707-9600-0002-0002, 1800-9600-0002-0002, 1801-9600-0002-0002, 1802-9600-0002-0002, 1803-9600-0002-0002, 1804-9600-0002-0002, 1805-9600-0002-0002, 1806-9600-0002-0002, 1807-9600-0002-0002

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini/
AMS 2 Pro/AMS HT



Scan for article

HMS 0700-9700-0003-0001: Chamber temperature of AMS A is relatively high; auxiliary feeding or RFID reading is not available currently.

Aliases: 0701-9700-0003-0001, 0702-9700-0003-0001, 0703-9700-0003-0001, 1800-9700-0003-0001, 1801-9700-0003-0001, 1802-9700-0003-0001, 1803-9700-0003-0001, 1804-9700-0003-0001, 1805-9700-0003-0001, 1806-9700-0003-0001, 1807-9700-0003-0001

X1 series/P1 series/P2S/
H2 series/ A1/A1 mini/
AMS 2 Pro/AMS HT



Scan for article

HMS 0700-9800-0002-0001: AMS A The power adapter voltage is too low, which may result in insufficient drying temperature. Please replace the power adapter.

Aliases: 0701-9800-0002-0001, 0702-9800-0002-0001, 0703-9800-0002-0001, 1800-9800-0002-0001, 1801-9800-0002-0001, 1802-9800-0002-0001, 1803-9800-0002-0001, 1804-9800-0002-0001, 1805-9800-0002-0001, 1806-9800-0002-0001, 1807-9800-0002-0001

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article

HMS 07FF-2000-0002-0001: External filament has run out; please load a new filament.

X1 series/P1 series/P2S



Scan for article

HMS 07FF-2000-0002-0002: External filament is missing; please load a new filament.

X1 series/P1 series/H2
series



Scan for article

HMS 07FF-2000-0002-0004: Please pull out the filament on the spool holder from the extruder.

X1 series/P1 series/H2
series



Scan for article

HMS 0C00-0100-0001-0004: Micro Lidar Lens dirty.

X1 series/P1 series



Scan for article

HMS 0C00-0100-0001-0009: Chamber camera dirty.

X1 series/P1 series



Scan for article

HMS 0C00-0100-0002-0008: Failed to get image from Live View Camera. Spaghetti and waste chute pileup detection is not available at this time.

X1 series/P1 series



Scan for article

HMS 0C00-0300-0003-0006: Purged filaments piled up.

X1 series/P1 series



Scan for article

HMS 0C00-0300-0003-0008: Possible spaghetti defects.

X1 series/P1 series



Scan for article

HMS 1800-7000-0002-0007: AMS-HT filament ran out. Please put a new filament into the same slot in AMS and resume.

Aliases: 1800-7000-0002-0007,1801-7000-0002-0007,1802-7000-0002-0007,1800-7003-0002-0007,1804-7000-0002-0007,1805-7000-0002-0007,1806-7000-0002-0007,1807-7000-0002-0007

X1 series/P1 series/P2S/
H2 series/A1/A1 mini



Scan for article