Step 1. Cut a USB Cable in half.




Step 2.

Remove Insulation and Shielding and Expose Wires.


Red = + 5V

Black = Ground


Green, White = Signal (we don't use)




Step 3: Cut off White and Green wires, and expose some insulation to red and black wire




Step 4. Solder the black wire (ground) to the side of a 3 pin head, and the red (power) to the middle.




Step 5: Find and Cut Orange and Black Header Connector Wire



Step 6: Solder Black Wire to the Ground, and the Orange to the Other Side.



Step 7: Protect with Electrical Tape to Avoid Shorts Due to Frequent Connections and Disconnects During Demos (Unseen in photo, I have electrical tape passing in between the solder joints).



Step 8: Cover with Heat Shrink tubing. You are finished!

