NORKHARATION: Check the sound a bench vice ?

1) PREPARATION: Check the job on a bench vice?

wing steel rule. Fix the job on a bench vice?

with and two affacent side using a just file to

with the segmen. Check for the prependicularity

form right augles. Check for the prependicularity

form right augles. Check for the prependicularity

with the segmen. Apply check on the work piece

20 num using Jenny caliper from the alteel rule.

20 num using Jenny caliper from the alteel rule.

Transfer the measured dimensions to the work piece


Transfer the measured dimensions along the dimensions

with edge 12 mm. Snaw lives along the dimensions

on work piece with scriber. Make dots along these

on work piece with scriber. Make dots along these

lines using dot punch.



3) DRILLING: Place the work piece on the drilling machine platform. Using drilling machine make two holes on the dotted place made by not punch. pour Some oil for smooth drill and drill the work piece properly by adjusting the pilot- Repeat the slops twice for better finishing. Lastly go to the thread pitch gauge machine & complete the driving procedure on the

LOOVE piece. 4) Tapping: Fix to work piece in the beach vice in Such a way that it should not move. using Tapping Tool I make threads & the holes. Repeat the procedure for noth. holes, then take the tapping tow 2 and use it carefully by rotating in clockwise, onwettaulously

do this process for both holes. 5) FINISHING: using a 10 nm screw, check the accuracy of the puish.

The required holes using allilling & Tapping techniques with proper measurements has been obtained.