Cut Sheet

Board Design Summary

- Style: scrap-chaotic
- Dimensions: 12.000" (12") × 18.000" (18") × 1.500" (1 1/2")
- Species: Walnut, Maple, Cherry
- Juice Groove: Perimeter loop, 0.492" ("H31/64") wide × 0.197" ("H13/64") dee
  corner radius 1.004" ("H1"), top face.
- Rubber Feet: 4 rubber feet, 1" (25.4 mm) diameter × 3/8" (9.5 mm) high, foo
  from the edges (underside).

[Step Diagram]

Cut List

Part	Qty	Width	Thickness	Length	Species
Maple blank (mill & rip, the	1n crosscu	3 19×51.4 mm ("H slices)	61. /8634 5"") ("H 1	5132/.6040"8) " ("H 1	Maple 1/ 6 4 ")
Walnut blank (mill & rip, th	1en crossc	3t.1×976.5 (mm 3 slices)	13/8634 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	5t.1×651.4 (mm 5 slices)	11/8634 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	1t.1×217.7 ("mm 1 slices	1/8"3) 5 " ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Maple blank (mill & rip, the	1n crosscu	4 19×74.7 mm ("H 4 slices)	31. /8332 5"") ("H 1	5132/.6040"8) " ("H 1	Maple 1/ 6 4 ")
Cherry blank (mill & rip, th	1en crossc	3t.19×597.9 mm 3 slices)	61/8634 5"") ("H 1	5132/.6040"8) " ("H 1	2Cherry 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	3t.15×984.8 (mm 3 slices)	19/8332 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Maple blank (mill & rip, the	1n crosscu	0 19×271.0 mm ("H 5 9/16 4 "3) 5 "	("H 1	5132/.6040"8) " ("H 1	Maple 1/ 6 4 ")
Walnut blank (mill & rip, th	1en crossc	4t.19×3109.8 ("mm 4 slices)	15/8136 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Cherry blank (mill & rip, th	1en crossc	6t.10×2183.5 ("mm 6 slices)	1/8323"5) [Width exceeds ("H 1	51jointer: use planer sled/or hand flatten]	("H 1 2Cherry 1/6 4 ")
Cherry blank (mill & rip, th	1en crossc	2t.11×261.4 mm 2 slices)	1/8"3) 5 " ("H 1	5132/.6040"8) " ("H 1	2Cherry 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	4t.11×0160.4.3 ("mm 4 slices)	7/643"5) " ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	2t.15×876.6 (mm 2 slices)	3/8634 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	3t.17×898.7 (mm 3 slices)	2/8332 5"") ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")
Maple blank (mill & rip, the	1n crosscu	2 19×612.3 (mm 2 slices)	31/8332 5"") ("H 1	5132/.6040"8) " ("H 1	Maple 1/ 6 4 ")
Maple blank (mill & rip, the	1n crosscu	2 16×821.1 mm ("H 2 slices)	11. /8136 5"") ("H 1	5132/.6040"8) " ("H 1	Maple 1/ 6 4 ")
Cherry blank (mill & rip, th	1en crossc	3t.15×247.1 mm 3 slices)	17/8332 5"") ("H 1	5132/.6040"8) " ("H 1	2Cherry 1/6 4 ")
Cherry blank (mill & rip, th	1en crossc	5t.10×167.1 mm 5 slices)	1/643"5) " ("H 1	5132/.6040"8) " ("H 1	2Cherry 1/6 4 ")
Walnut blank (mill & rip, th	1en crossc	2t.12×247.1 (mm 2 slices)	7/8323"5) " ("H 1	5132/.6040"8) " ("H 1	2Walnut 1/6 4 ")

Board Layout (Top View)

[Step Diagram]

Step 1: Mill rough stock

Joint one face and one edge on the jointer, then plane to final thickness plus 1/8" (3 mm). Rest overnight, then plane to final thickness. Take ~1/64" (0.4 mm) passes for the last two passes.

Settings:

Final pass depth: ~1/64" (0.4 mm)

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.

[Step Diagram]

Step 2: Sort offcuts

Discard pieces with checks, knots or softwood. Only pieces at least 12" (305 mm) long go through the jointer and planer; glue shorter offcuts onto a 305 mm carrier panel first or sand them to thickness. Cut pieces of 6" (152 mm) or less only on a sled with a hold-down.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

Step 3: Glue up

Glue offcuts into rough panels. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 4: Crosscut slices

Crosscut slices on a crosscut sled with a stop block.

DANGER: Never use the rip fence as a length stop for crosscuts. Use a crosscut sled with a stop block set before the blade, so the offcut is never trapped between blade and fence.

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

[Step Diagram]

Step 5: Glue up

Glue slices end grain up in random order. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 6: Flatten and sand

Flatten with a router sled or drum sander, never the thickness planer. Sand 80, 120, 180 grit. Break edges (180 grit).

Settings:

Grits: 80 / 120 / 180

DANGER: Never run an end-grain glue-up through the thickness planer. It can blow apart. Flatten with a router sled or drum sander.

[Step Diagram]

Step 7: Edge profile

Rout the edge profile, default: 1/8" (3 mm) roundover. Optional finger grips: core box / round-nose bit 3/8–1/2" (9.5–12.7 mm).

Settings:

Bit: 1/8" (3 mm) roundover

WARNING: Climb cuts can grab. Feed the router against the bit rotation and take shallow passes.

[Step Diagram]

Step 8: Finish

Raise the grain with a damp cloth, sand 180 again, then flood with food-safe mineral oil and top with board butter.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.