Cut Sheet

Board Design Summary

Style: scrap-chaotic

Dimensions: 12.000" (12") × 18.000" (18") × 1.500" (1 1/2")

Species: Walnut, Maple, Cherry

Juice Groove: Perimeter loop, 0.492" ("H31/64") wide × 0.197" ("H13/64") dee
corner radius 1.004" ("H1"), top face.

Rubber Feet: 4 rubber feet, 1" (25.4 mm) diameter × 3/8" (9.5 mm) high, foo
from the edges (underside).

[Step Diagram]

Cut List

Part	Qty	Width	Thickness	Length	Species
Maple blank (mill & rip, then crosscut, 3 slices)	1	3.19×57.4 mm ("H3 slices)	61.8635"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 M a p l e 6 4 ")
Walnut blank (mill & rip, then crosscut, 3 slices)	1	3.11×97.6 mm ("H3 slices)	118.8635"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Walnut blank (mill & rip, then crosscut, 5 slices)	1	5.11×65.1 mm ("H5 slices)	141.8635"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Walnut blank (mill & rip, then crosscut, 1 slices)	1	1.11×217.7 mm ("H1 slices)	118.83 5 "	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Maple blank (mill & rip, then crosscut, 4 slices)	1	4.19×72.7 mm ("H4 slices)	61.8325"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 M a p l e 6 4 ")
Cherry blank (mill & rip, then crosscut, 3 slices)	1	3.19×59.7 mm ("H3 slices)	61.8635"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 C h e r r y 6 4 ")
Walnut blank (mill & rip, then crosscut, 3 slices)	1	3.15×98.4 mm ("H3 slices)	149.8325"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Maple blank (mill & rip, then crosscut, 1 slices)	1	1.19×27.0 mm ("H1 slices)	36.4 3 5	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 M a p l e 6 4 ")
Walnut blank (mill & rip, then crosscut, 4 slices)	1	4.19×130.8 mm ("H4 slices)	118.8136"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Cherry blank (mill & rip, then crosscut, 6 slices)	1	6.10×213.5 mm ("H6 slices)	177.8 3 5	(exceed jointer, use planer sled or hand flatten]	
Cherry blank (mill & rip, then crosscut, 2 slices)	1	2.11×26.1 mm ("H2 slices)	118.83 5 "	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 C h e r r y 6 4 ")
Walnut blank (mill & rip, then crosscut, 4 slices)	1	4.11×160.3 mm ("H4 slices)	71.6843"5)	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Walnut blank (mill & rip, then crosscut, 2 slices)	1	2.15×87.6 mm ("H2 slices)	94.8635"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Walnut blank (mill & rip, then crosscut, 3 slices)	1	3.17×98.7 mm ("H3 slices)	245.8325"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")
Maple blank (mill & rip, then crosscut, 2 slices)	1	2.19×61.9 2.3 mm ("H2 slices)	94.8325"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 M a p l e 6 4 ")
Maple blank (mill & rip, then crosscut, 2 slices)	1	2.16×82.1 mm ("H2 slices)	141.8136"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 M a p l e 6 4 ")
Cherry blank (mill & rip, then crosscut, 3 slices)	1	3.15×224.1 mm ("H3 slices)	149.8325"")	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 C h e r r y 6 4 ")
Cherry blank (mill & rip, then crosscut, 5 slices)	1	5.10×126.1 mm ("H5 slices)	141.6843"5)	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 C h e r r y 6 4 ")
Walnut blank (mill & rip, then crosscut, 2 slices)	1	2.12×224.1 mm ("H2 slices)	76.3823"5)	("H 1 5 1 3 2 / 6 4 0 ")	("H 1 W a l n u t 6 4 ")

Board Layout (Top View)

[Step Diagram]

Step 1: Mill rough stock

Joint one face and one edge on the jointer, then plane to final thickness plus 1/8" (3 mm). Rest overnight, then plane to final thickness. Take ~1/64" (0.4 mm) passes for the last two passes.

Settings:

Final pass depth: ~1/64" (0.4 mm)

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Keep hands clear of the infeed and outfeed. Feed only boards at least 12" (305 mm) long.

[Step Diagram]

Step 2: Sort offcuts

Discard pieces with checks, knots or softwood. Only pieces at least 12" (305 mm) long go through the jointer and planer; glue shorter offcuts onto a 305 mm carrier panel first or sand them to thickness. Cut pieces of 6" (152 mm) or less only on a sled with a hold-down.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.

WARNING: Use push blocks on the jointer. Never joint stock shorter than 12" (305 mm) or thinner than 1/2" (12.7 mm).

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

Step 3: Glue up

Glue offcuts into rough panels. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 4: Crosscut slices

Crosscut slices on a crosscut sled with a stop block.

DANGER: Never use the rip fence as a length stop for crosscuts. Use a crosscut sled with a stop block set before the blade, so the offcut is never trapped between blade and fence.

WARNING: Do not cut pieces shorter than 6" (152 mm) free-hand on the table saw. Use a sled with a hold-down.

[Step Diagram]

Step 5: Glue up

Glue slices end grain up in random order. Alternate clamps above and below the panel and check for flat with a straightedge.

Settings:

Clamp spacing: about 8" (200 mm)

NOTE: Use a waterproof PVA glue rated for indirect food contact. Clamp until squeeze-out turns rubbery, then scrape.

[Step Diagram]

Step 6: Flatten and sand

Flatten with a router sled or drum sander, never the thickness planer. Sand 80, 120, 180 grit. Break edges (180 grit).

Settings:

Grits: 80 / 120 / 180

DANGER: Never run an end-grain glue-up through the thickness planer. It can blow apart. Flatten with a router sled or drum sander.

[Step Diagram]

Step 7: Edge profile

Rout the edge profile, default: 1/8" (3 mm) roundover. Optional finger grips: core box / round-nose bit 3/8–1/2" (9.5–12.7 mm).

Settings:

Bit: 1/8" (3 mm) roundover

WARNING: Climb cuts can grab. Feed the router against the bit rotation and take shallow passes.

[Step Diagram]

Step 8: Finish

Raise the grain with a damp cloth, sand 180 again, then flood with food-safe mineral oil and top with board butter.

NOTE: Use closed-grain, non-toxic hardwoods only. Avoid spalted, softwood or oily/sensitising exotics on cutting surfaces.