

the panel on

- SCREW

Then, solder the

t should work fine

O




POTENTIOMETERS

& switch

Jacks

if it's OK





3D-printed panel