



Steps of Operation

Open V-Carve Pro

- Create a New File
- Put in the correct Parameters for the Job Setup
- When the drawing screen appears, located under the Create Vectors section are tools used for drawing. Select an icon and fill in the parameter boxes according to your specifications. After the necessary information is filled in click the Create button and your drawing will appear in the drawing window located to the right of the drawing tool window!
- After your drawing has been created you will then highlight all vectors in there entirety and save as follows: File->Export->Selected Vectors to DXF

Open SheetCam

- Open the drawing you wish to create a tool path for using the following steps of operation: File->Import Drawing->Open the necessary drawing
- A drawing options window will appear (Select Units as "Inches" and the drawing origin as the bottom left then click "OK")
- The drawing will then appear in the display window
- On the left side of the screen is a section labeled Operations. The first tool in this section is "Create a New Jet Cutting Operation". Select this tool and a window will appear that will allow you to set up the necessary parameters to create your desired toolpath! Fill in all necessary information and click "OK"
- A toolpath should appear around your drawing
- The next step is to run the post processor to generate the G-Code for the drawing! This is done by simply clicking on the Small Green "P" at the top left corner of the screen. This will save the file as a (.tap) which will be recognized by Mach 3!



Open Mach 3

- First you will hit the “Reset” button to establish communication to the machine. (The button should quit flashing if there are no interruptions in the communication between the machine and the controller)
- Then reference the Machine using the “Ref All Axis” button located in the center of the screen directly under the DRO!
- After referencing, move the machine to the desired zero location for the Cut. When this location has been identified with both X and Y axis you must then jog the torch down to within .5” of the top of the material!
- The next step is to zero all 3 axis. This is done by clicking the (Zero X, Zero Y, and Zero Z) buttons directly to the left of the DRO.
- Now you can load your G-Code. The “Load G-Code” button is directly under the “Cycle Start” button on the left side of the Mach screen.
- When the G-Code is finished loading you will then turn on your THC using the “THC ON” button located under the DRO on the Mach screen. Then set your THC to the required arc voltage!
- You are now ready to start the cut file! Do this by clicking the “Cycle Start” button.