



Print Automation

A1 & A1 Mini

Before implementing these codes please watch the whole corresponding video first to not damage your printer !!!

→ [Automation_Tutorial_YouTube_Video](#)

Depending on the model this still needs a little custom configuration. If followed correctly, this should be safe for your printer.

However, implementing this comes at your own risk, and I am in no way liable for any damage or issues that may occur.

I hope you enjoy and a heartfelt thank you to everyone who supports my work through commercial licenses, by buying my 3D models and being an active community member!

All files & content downloaded from:

→ [Factorian Designs](#)





Process Checklist

1. Select automation printer profile
2. Position model at correct spot
3. Check self-release settings
4. Check end g-code:
 - z-push off height
 - (ok y-coordinates for side push off)
5. Slice model and export as .gcode.3mf:
 - (increase extrusion first moves)
 - Loop print
6. Re-zip and rename file to .gcode.3mf
7. Open and send file to printer
8. Make sure no negative z move

commands are in the Slicer preview !!!

(This should never happen with my standard code)

All files & content downloaded from:

→ [Factorian Designs](#)