

## STEPPER MOTOR PINOUT 1B 1A 2A 2B

## STEPPER DRIVER SOCKET PINOUT

	LEFT		RIGHT —
TRADITIONAL	SPI	UART	
ENABLE	ENABLE	ENABLE	UMOT
MS1	SPI-MOSI		GND
MS2	SPI-SCK		2B
MS3	SPI-CS	UART RX & TX (1K)	2A
<b>P</b> RESET	SPI-MISO		1A
L <sub>SLEEP</sub>			1B
STEP	STEP	STEP	VIO
DIRECTION	DIRECTION	DIRECTION	GND

## DIAG PINOUT

	DIAG
--	------

## STEPPER DRIVER JUMPERS SLP MS3 MS2 MS1

SLP	+3/3	+3V3	+3/3
RST	MS3	MS2	MS1
SPI-MISO	SPI-CS UART	SPI-SCK	SPI-MOSI