

STEPPER MOTOR PINOUT 1B 1A 2A 2B

STEPPER DRIVER SOCKET PINOUT

		LEFT		ſ	💳 RIGHT 💳
•	TRADITIONAL	SPI	UART	_	
	ENABLE	ENABLE	ENABLE		UMOT
	MS1	SPI-MOSI			GND
	MS2	SPI-SCK			2B
	MS3	SPI-CS	UART RX & TX (1K)		2A
	F RESET	SPI-MISO			1A
	L _{SLEEP}				1B
	STEP	STEP	STEP		VIO
	DIRECTION	DIRECTION	DIRECTION		GND

DIAG PINOUT

D	IAG
---	-----

STEPPER DRIVER JUMPERS SLP MS3 MS2 MS1

SLP	+3/3	+3V3	+3/3
RST	MS3	MS2	MS1
SPI-MISO	SPI-CS UART	SPI-SCK	SPI-MOSI