Analysis of electric power and energy systems

Lecture 5: Synchronous generators

Bertrand Cornélusse bertrand.cornelusse@uliege.be



What will we learn today?

- What are synchronous generators
- How we can model them for our analyses
- How to include generator limits in power flow computation.

You will be able to do exercises TODO

Principle


Synchronous machines

Synchronous machines produce the major part of the electric energy

- range from a few kVA to a few hundred MVA
- the biggest are rated 1500 MVA

They play other important roles:

- they impose the frequency of sinusoidal voltages and currents
- they provide an "energy buffer" (through the kinetic energy stored in their rotating masses)
- they can produce or consume reactive power (needed to regulate voltage).




Magnetic field created by the stator

Magnetic field created by the stator

- stator (or armature) = motionless, separated from the rotor by a small air gap
- subjected to varying magnetic flux ⇒ built up of thin laminations to decrease eddy (or Foucault) currents
- equipped with three windings, distributed 120 degrees apart in space.

Magnetic field created by a direct current flowing in one of the stator windings:




The magnetic field lines cross the air gap radially.

The amplitude $B(\varphi)$ of the magnetic flux density at point P :

- is a periodic function of arphi with period 2π
- this function has a "staircase" shape
- is made as close as possible to a sinusoid, by properly distributing the conductors along the air gap.

Layout of the three phases (each winding represented by a single turn for clarity):



Total flux density created by the three phases at point P corresponding to angle φ :


$$B_{3\phi}(arphi)=ki_a\cosarphi+ki_b\cos(arphi-rac{2\pi}{3})+ki_c\cos(arphi-rac{4\pi}{3})$$

If three-phase alternating currents are flowing in the windings:

$$B_{3\phi}(arphi)=rac{3\sqrt{2kI}}{2}\cos(\omega t+\psi-arphi)$$

The three-phase alternating currents all together produce the same magnetic field as a magnet (or a coil carrying a direct current) rotating at the angular speed ω

- North pole of magnet \equiv maximum of $B(\varphi)$
- South pole of magnet \equiv minimum of $B(\varphi)$




Magnetic field created by the rotor

Magnetic field created by the rotor

- rotor = rotating part, separated from the rotor by the air gap
- carries a winding in which a direct current flows, in steady-state operation
- referred to as field winding (in French: enroulement d'excitation)


Magnetic field created by this direct current (field winding represented by a single turn for clarity):



Interaction between magnetic fields and electromechanical conversion

- In a synchronous machine, in steady state, the rotor rotates at the same angular speed ω as the magnetic field produced by the stator
- thus, the stator and rotor magnetic fields are fixed with respect to each other
- both fields tend to align in the manner of two magnets
- if one pulls apart those two magnets, an electromagnetic torque appears.

Mechanical analogy:



generator operation <-> motor operation


There exists a max value of the electromagnetic torque $T_e
ightarrow 1$ loss of synchronism

The two types of synchronous machines

Machines with multiple pairs of poles

Some turbines operate at a lower speed, but AC voltages and currents at the stator must keep the same period $T=\frac{1}{f}$

- the rotor carries *p* pairs of poles
- during a period T, the rotor makes only $\frac{1}{p}$ of a whole revolution
- the stator carries p sets of (a, b, c) windings
- one winding spans an angle of $\frac{\pi}{p}$ radians
- ullet during a period T, each stator winding is still swept by one North and one South pole of rotor.



example: p=2


Machines with multiple pairs of poles (...)

Speed:
$$\frac{3000}{p}$$
 rev/min at 50 Hz

The various windings relative to a given phase are connected (in series or parallel) to end up with a three-phase machine.

Caution: p sometimes denotes the number of poles, sometimes the number of pairs of poles.


Round-rotor generators (or turbo-alternators)



Driven by steam or gas turbines, which rotate at high speed

- p=1 (conventional thermal units) or p=2 (nuclear units)
- cylindrical rotor made up of solid steel forging
- diameter << length (centrifugal force!)
- field winding made up of conductors distributed on the rotor, in milled slots
- even if the generator efficiency is around 99 %, the heat produced by Joule losses has to be evacuated! Large generators are cooled by hydrogen (heat evacuation 7 times better than air) or water (12 times better) flowing in the hollow stator conductors.

Salient-pole generators



- Driven by hydraulic turbines (or diesel engines), which rotate at low speed
- p is much higher (at least 4) ⇒ it is more convenient to have field windings concentrated and placed on the poles
- diameter >> length (to have space for the many poles)
- rotor is laminated (poles easier to construct)
- generators usually cooled by the flow of air around the rotor.

Damper windings (or amortisseurs)

- round-rotor machines: copper/brass bars placed in the same slots at the field winding, and interconnected to form a damper cage (similar to the squirrel cage of an induction motor)
- salient-pole machines: copper/brass rods embedded in the poles and connected at their ends to rings or segments.

Why?

- in perfect steady state: the magnetic fields produced by both the stator and the rotor are fixed relative to the rotor ⇒ no current induced in dampers
- after a disturbance: the rotor moves with respect to stator magnetic field
 ⇒ currents are induced in the dampers...
 - ... which, according to Lenz's law, create a damping torque helping the rotor to align on the stator magnetic field.

Remark: in round-rotor generators: the solid rotor offers a path for eddy currents, which produce an effect similar to those of dampers.

Model

Induced emf in the stator windings


There are two sources that induce an emf (electromotive force) in the stator windings.

- ullet the effect of the rotor's induced field ($ar{E}_{af}$)
- the effect of the current flowing in the stator itself, called the armature reaction ($-jX_s \bar{I}_a$).

By superimposing them, we get the resulting emf.

We assume there is no magnetic saturation.

Per phase equivalent circuit (for phase a)




- R_s is the resistance of a phase
- ullet the synchronous reactance X_s characterizes the steady-state operation of the machine (magnetizing + leakage reactances)
- δ , the phase shift between the internal emf \bar{E}_{af} and the terminal voltage \bar{V}_a , is called the internal angle or load angle of the machine.

We thus have

$${ar V}_a={ar E}_{af}-R_s\,{ar I}_a-jX_s\,{ar I}_a$$

Phasor diagram representation



Machine parameters in per unit on the machine base

$$R_spprox 0.005\,\mathrm{pu}$$

 $X_s \in [1.5, 2.5]$ pu (for a round-rotor machine as considered in this lecture)

Remark: models for other types of analysis

So far we are mostly interested in steady-state.

But note that depending on the type of analysis carried out, the model used should be adapted:


- Subtransient condition (e.g. just after a short circuit fault): $X_s^{\prime\prime} << X_s$
- ullet transient state (after the subtransient condition, before steady state): $X_s' < X_s$ but $X_s' < X_s''$

The field induced emf has to be adapted as well depending on the type of analysis.

Properties of the model

Power output, stability, and loss of synchronism

Suppose a generator is connected to an external grid (imposing $\bar{V}_{\infty}=V_{\infty}$) through a transmission line.



Let X_T model the total reactance resulting from the reactance of the line, the reactance of the transformer, and the synchronous reactance of the machine. We neglect resistances.

The three phase active power delivered by the generator is (see lecture 2)

$$P=rac{E_{af}V_{\infty}}{X_{T}}\sin\delta$$

About the internal angle δ

The angle δ

- is the angle between $ar{E}_{af}$ and $ar{V}_{\infty}$
- is positive in generator mode
- is a measure of the angular displacement of the rotor with respect to the synchronously rotating reference axis

If the field current is constant, E_{af} is constant. Then the power of the generator is proportional to $\sin \delta$.

There are limits on the value of δ .

Steady state stability limit




FIGURE 9.12 Steady state stability limit.

Above $\delta=90^\circ$ (maximum power generated), the synchronism is lost:

- more mechanical power, less electrical power \Rightarrow increase of $\delta \Rightarrow$ too high currents


In practive the limit is well below, at around $\delta=40^\circ$

Adjusting reactive power

We take the previous example and we want

- to keep the same active power generation
- to adjust the reactive power generated or absorbed

Initially, assume the field current is adjusted to have a unitary power factor (case 1)




What can we do?

Adjusting reactive power

We take the previous example and we want

- to keep the same active power generation
- to adjust the reactive power generated or absorbed

Initially, assume the field current is adjusted to have a unitary power factor (case 1)



What can we do?

By controlling the field current, it is possible to control the induced emf and the reactive power delivered (or absorbed).

Overexcitation (case 2)

- ullet Increasing the field current will increase E_{af} (no magnetic saturation)
- ullet But $E_{af}\sin\delta$ must stay the same, and $I_a\cos\phi$ as well
- ullet $ar{I}_a$ is lagging behind $ar{V}_a$
- The grid absorbs the reactive power

$$Q = 3V_a I_a \sin \phi$$

• The generator behaves like a capacitor

Underexcitation (case 3)

- ullet Decreasing the field current will decrease E_{af}
- ullet But $E_{af}\sin\delta$ must stay the same, and $I_a\cos\phi$ as well
- ullet $ar{I}_a$ is leading $ar{V}_a$
- The generator absorbs the reactive power

$$Q = -3V_aI_a\sin\phi$$

The generator behaves like an inductor


Remarks:

- This is the basic principle behind automatic voltage regulation
- Devices called "synchronous condensers" are synchronous machines used solely for voltage regulation (they consume active power from the grid).

Capability curves

Seen from the network, a generator is characterized by three variables: V,P et Q

The capability curves define the set of admissible operating points in the (P,Q) space, under constant voltage V (justified by automatic voltage regulator)



Explanation of limits

- Lower limit on active power caused by stability of combustion in thermal power plants
- maximum reactive power increases when the active power decreases
 - \circ to relieve an overloaded machine, P can be decreased but this power has to be produced by some other generators!
- ullet for a given value of P, the maximum reactive power increases with V
 - this holds true under the simplifying assumption of a non saturated machine
- ullet in practice, under V=1 pu, the two-by-two intersection points of respectively the turbine, the rotor and the stator limits are close to each other ("coherent" design of stator and rotor)
- Under-excitation limit
 - \circ Corresponds to a stability, not a thermal limit: absorbing more $Q\Rightarrow$ decreasing $E_{af}\Rightarrow$ decreasing field current \to maximum torque T_e decreases \Rightarrow risk of losing synchronism (see course on voltage regulation).

Synchronous generators in the power flow analysis

Reaching the bus var limit

Given what we have established, this is straightforward:

- Implement the bounds of the capability curves in the power flow tool
 - How would you do this?
- Solve assuming generators regulate P and $V \Rightarrow \mathsf{PV}$ bus
- If a boundary of the capability domain is reached
 - switch the generator to a PQ bus with the same P but the binding Q
 - solve the power flow again

This may require iterations, since other generators could need a switch.

See section 5.10 of the book

Example with PandaPower

See the python notebook.

References

- Course notes of ELEC0014 by Pr. Thierry Van Cutsem.
- Mohan, Ned. Electric power systems: a first course. John Wiley & Sons, 2012.
- L. Thurner, A. Scheidler, F. Schäfer et al, pandapower an Open Source Python Tool for Convenient Modeling, Analysis and Optimization of Electric Power Systems, in IEEE Transactions on Power Systems, vol. 33, no. 6, pp. 6510-6521, Nov. 2018.

The end.