

SOP-002 - Hot Work Permit Procedure

Standard Operating Procedure | Tier 1

1. Purpose

To control ignition sources during welding, grinding or cutting in process areas.

2. Procedure

1. Identify the hot-work location and surrounding hazards.
2. Obtain a hot-work permit signed by the area authority.
3. Gas-test the area; confirm below 10% LEL before starting and periodically during work.
4. Remove or cover combustibles within 15 m; provide a fire watch and extinguisher.
5. Isolate and blind any connected process lines.
6. Perform the work; maintain the fire watch for 30 minutes after completion.
7. Close out the permit and confirm the area is safe.