

## TRANSMISSION OF POWER

#### Introduction:

 Mechanical energy developed by prime mover has to be transmitted to the required utility by a transmission system.







#### **Methods of Drive**

Machines may be driven by any one of the following

two methods:

1. Individual Drive

2. Group Drive







## Individual Drive (Self-contained Drive)

- Each machine has its own electric motor(prime mover) and starter.
- The motor may drive the machine shaft through belt, chain, gears etc.
- Used for machines that needs to be operated independently or requiring considerable power.



## **Group Drive**

A very powerful motor drives an overhead shaft (Main shaft),

that runs from one end to other end of the shop.

**Main shaft** in turn drives the individual machine drive shafts.

Group drive is economical in terms of power consumption and maintenance.



## Factors for selecting a transmission system

- Distance between driver and driven shaft.
- Operating speed.
- Power to be transmitted.



## Types of transmission system

- i. Belt drive Flat belt V belt
- ii. Chain drive.
- iii. Gear drive.
- iv. Rope drive.



## **Belt Drive (Friction Drive)**



One of the most common and effective devices for transmitting

motion from one shaft to another by means of a thin inextensible


band running over two pulleys.

Applications: Mills, Factories and Machine tools.






## **Belt Drive**



- Used when power is to be transmitted between two parallel shafts.
- Consists of two pulleys and an endless belt which passes over the two pulleys.
- Rotary motion is transmitted from driving pulley to driven pulley.

#### **Belt Drive**




- For the belt to move tension on one side of the belt should be more than the tension on the other side
  - Portion of the belt having high tension is called tight side.
  - Portion of the belt having less tension is called slack side.
  - Friction is a helpful agent.




## **Types of belt drives:**

- 1. Open belt drive
- 2. Crossed-belt drive















- Employed when the two parallel shafts have to rotate in the same direction.
- ➤ When the shafts are placed far apart, the lower side of the belt should be the tight side and the upper side must be the slack side.
- > The shaft axes should be horizontal and should never be vertical.



# Crossed belt drive







#### **Crossed belt drive**

- > Used when two parallel shafts have to rotate in the opposite direction.
- ➤ At the junction where the belt crosses, it rubs against itself and wears off.
- > To minimize rubbing, speed of belt should be less and the shafts should be at maximum distance apart.
- > Power transmitted is more because of larger angle of contact as compared to open belt drive.

Open Belt Drive	Crossed Belt Drive
_	
Driver and driven shafts rotate in	Driver and driven shafts rotate in
same direction.	opposite direction
As there is no rubbing, life of the	Due to rubbing, life of the belt
belt is more	reduces.
Requires less length of the belt.	Requires more length of belt.
Lesser power transmission.	Power transmitted is relatively
	higher.



# Velocity Ratio of Belt Drive. (Speed Ratio)

The velocity ratio of a belt drive is defined as the ratio of the speed of the driven pulley to the speed of the driving pulley.



#### Expression for velocity ratio of belt drive.

Let

 $d_1$ = Diameter of the driving pulley (mm),

 $d_2$ = Diameter of the driven pulley (mm).

 $N_1$ = Speed of the driving pulley (RPM)

 $N_2$ = Speed of the driven pulley (RPM)

Assuming there is no relative slip between the pulleys and the

portions of the belt which are in contact with them

The linear speed at every point on the belt should be same

The circumferential speeds of the driving and driven pulleys and the linear speed of the belt are equal.

$$\begin{bmatrix} Linearspeed \\ of the belt \end{bmatrix} = \begin{bmatrix} Circumferential speed \\ of the driving pulley \end{bmatrix} = \begin{bmatrix} Circumferential speed \\ of driven pulley \end{bmatrix}$$

$$= \Pi d1N1 = \Pi d2N2$$

$$= d1N1 = d2N2$$

Velocity Ratio = 
$$N_2 / N_1 = d_1 / d_2$$



$$= \frac{Speed of the driven pulley}{Speed of the driving pulley} = \frac{Diameter of the driving pulley}{Diameter of the driven pulley}$$


## **Types of pulleys**

• Stepped cone pulley (Speed cone)

Fast and loose pulley



## **Stepped cone pulley**










## **Stepped cone pulley**

- When speed of the driven shaft is to be changed very frequently.
- ➤ One set of stepped cone pulley is fixed on the driving shaft and another similar pulley in reverse direction on the driven shaft.
- ➤ By shifting the belt from one pair of pulleys to another different speeds of the driven shaft can be obtained.

Used in lathe, drilling m/c etc.

## **Fast and Loose pulley**







## **Fast and Loose pulley**

- When several machines obtain the drive from a common main driving shaft, it may be required to run some machines intermittently without having to **Start** or **stop** the main driving shaft. Fast and Loose pulley arrangement enables individual machines to be started or stopped at will.
- ➤ It has a Fast pulley which is securely **keyed** to the driven shaft and a Loose pulley (with bush / bearing) which is free to rotate on

the driven shaft.

## Working

When the belt is on the fast pulley

Power transmitted to the driven shaft.

When the driven shaft is to be brought to rest,

Belt is shifted from fast pulley to loose pulley



## **Initial Tension in the belt**

when the drive is on, the increase in tension on the tight side must always be equal to the decrease in tension on the slack side as there is no stretching of the belt.

$$T_1 - T_0 = T_0 - T_2$$

$$T_1 + T_2 = 2T_0$$

$$T_0 = \frac{T_1 + T_2}{2}$$



## Slip in Belt Drives

Sliding of the belt which causes a relative motion between the pulley surface and the belt is called slip.

#### Slip occurs:

- when the coefficient of friction between the belt and pulley surface decreases owing to stretching of the belt.
- when the smoothness of the pulley surface is more.
- when the differences between tensions in the tight and slack sides is very large.

**Effect of slip on the Velocity Ratio** 

$$\therefore \frac{N_2}{N_1} = \frac{d_1}{d_2} \times \left[ \frac{100 - S}{100} \right]$$



## **Creep in Flat belt drive**


The phenomena of *alternate stretching* and *contraction* of the belt which results in a relative motion between the belt and the pulley surface is called creep.

#### This results in:

- > Loss of power.
- > Decrease in the velocity ratio.




## **Length of a belt**





$$L = \Pi(r_1 + r_2) + \frac{(r_1 - r_2)^2}{X} + 2X$$

# **Arc of contact**




Angle of lap = 
$$\theta = \pi - 2\phi$$

$$\phi = \sin^{-1} \left( \frac{r_1 - r_2}{X} \right)$$



## Length of a belt

#### **Crossed belt drive:**








$$L = \Pi(r_1 + r_2) + \frac{(r_1 + r_2)^2}{X} + 2X$$

#### **ARC OF CONTACT**

#### Crossed belt drive



Lenth of Belt - Crossed Belt Drive

Magle of lap =  $\theta = \pi + 2\phi$ 

$$\emptyset = \sin^{-1}\frac{(r_1 + r_2)}{X}$$

**Department of Mechanical and Manufacturing Engineering** 

# Power transmitted by a Belt drive

If v is the linear velocity of the belt m/min and  $T_1$  and  $T_2$  are the tensions on the tight and slack sides of the belts expressed in Newton, then


Work transmitted per second = 
$$\frac{(T_1 - T_2) \times v}{60}$$

Power transmitted = 
$$\frac{(T_1 - T_2) \times v}{60 \times 1000} kW$$

Where v= Πd1N1 = Πd2N2 d1, d2 are the diameters in metres & N1, N2 are the RPM's of driver & driven pulleys respectively



## Ratio of Tensions in Flat Belt Drive



where,

 $\theta$  = Arc of contact in radians

 $\mu$  = Coefficient of friction

 $T_1$  and  $T_2$  are the tensions on the tight and slack sides of the belts expressed in Newtons

## Disadvantages of flat belts

- Not suitable for small center distance
- Exact velocity ratio cannot be maintained
- Slip & creep causes loss of power
- Large power cannot be transmitted effectively

