ACCELERATOR PEDAL POSITION (APP) SENSOR INSPECTION [SKYACTIV-G 2.0]


id0140f4803200

Voltage Inspection

Note

- Because the APP sensor is integrated in the accelerator pedal, replacing the APP sensor includes replacement of the accelerator pedal.
- 1. Connect the M-MDS to the DLC-2.
- 2. Switch the ignition ON (engine off or on).
- 3. Verify that the APP sensor output voltage (PID: APP1, APP2) increases according to the increase in the accelerator opening angle when the accelerator opening angle is gradually increased. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].)
 - · If verified, go to the next step.
 - If not as verified, replace the accelerator pedal. (See ACCELERATOR PEDAL REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)
- 4. Verify that the APP sensor output voltage (PID: APP1, APP2) is within the specification when the accelerator pedal is depressed and not depressed. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0].) (See PCM INSPECTION [SKYACTIV-G 2.0].)
 - If not as specified, replace the accelerator pedal. (See ACCELERATOR PEDAL REMOVAL/INSTALLATION [SKYACTIV-G 2.0].)

Specification



am3uun00001684