
POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5]

id0140g2889400

Voltage Inspection

- 1. Connect the M-MDS to the DLC-2.
- 2. Switch the ignition ON (engine off).
- 3. Verify that the power brake unit vacuum sensor output voltage (PID: BBP) is within the specification. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) (See PCM INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
 - If not within the specification, replace the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM SENSOR REMOVAL/INSTALLATION.)

Specification



ac5wzw00006367