## 7-1. Components on the Front, Rear Case




## 7-2. Pre-requisite




## 7-3. Parts which must be changed after repair

BOM description & part code	Image	Remarks
A/S-SVC HR TAPE [GH81-15706A]		Replace for
A/S-SVC Main Window Rework Tape [GH81-15705A]		OCTA TA


#### 7-4. Disassembly








#### 7-5. Assembly



Assemble Front Assy and Rear Assy, (Firstly, Bottom side assemble and then totally assemble)

6 Screw 18 Point and disassemble SIM Tray
Torque Spec : Spec : 1.3 ± 7%





- Caution
- 1) Be care of scratch
- 2) Be care of PBA Component damage

- Caution
- 1) Be care of scratch
- 2) Be care of Torque spec

7

Attach OCTA Tape on OCTA



8

Assemble OCTA Connector, Connector CAP Attach OCTA





- Caution
- 1) Be care of OCTA damage
- 2) Be care to attach tape, Cu Sheet on OCTA properly
- Caution
- 1) Be careful of FPCB damage

