

W5500
STATUS
RESET
BOOT
USB-C
PWR
CHG
EXPANSION (see guide)
QWIIC
DC IN
TAMPER
EXT TAMPER
3V2
ERM
LED BEEP DO D1 +12V GND A B +12V GND
6-36V GND
IN1
IN2
GND
IN3
IN4
GND
RST DC CS MOSI SCK GND 3V3
3V3 GND SCK MOSI MISO CS INT RST
NC NO COM NC
T T - +