Micrometer



Category: **Measuring & Marking Tools** Type: **Short SOP** Priority: **Medium** 7 labs

Covers these lab items: Micrometer; Out - Side Micromet er; Out - Side Micromet er Digital

What it is used for

Use a micrometer to measure small external dimensions, such as wire, shaft, or component thickness, with high precision.

How to use

1. Select a micrometer with a range and resolution suitable for the part.
2. Inspect the anvil, spindle, frame, ratchet, and display or scale for damage.
3. Clean the measuring faces and the workpiece before measurement.
4. Check zero setting or calibration according to the instrument instructions.
5. Place the workpiece between the anvil and spindle without tilting it.
6. Turn the ratchet or friction device gently until the measuring force is consistent.
7. Read the scale or digital display and record the measurement with units.
8. Open the spindle, remove the part, and store the micrometer carefully.

⚠ Safety

- Do not force the spindle or overtighten the ratchet.
- Keep fingers clear of pinch points between the measuring faces.
- Do not measure moving or energized components.
- Use the micrometer only within its specified range and avoid dropping it.

Care & storage

- Wipe the measuring faces clean and dry after use.
- Store in its case and arrange calibration as specified.

Disclaimer: This SOP is prepared from general information available on the internet. For detailed instructions, refer to the manufacturer's original manual / file.