

# Embedded Systems (EPM)

Lecture (7) Summary

#### **1 - Relay:**

it's an electrically operated switch consists of a set of input terminals for a single or multiple control signals, and a set of operating contact terminals.

The switch may have any number of contacts in multiple contact forms, such as make contacts, break contacts, or combinations thereof.

Relays used to control a circuit by an independent low-power signal.


Traditional form uses an electromagnet to close or open the contacts, but other operating principles have been invented such as:

in solid-state relays which use semiconductor properties for control.

## Relay(Ex.)

```
Ammeter
```

```
4 #define OUT_PIN 2
5 void setup() {
6   pinMode(OUT_PIN,OUTPUT);
7   digitalWrite(OUT_PIN,HIGH);
8 }
9 void loop() {
10   digitalWrite(OUT_PIN,LOW);
11   delay(1000);
12   digitalWrite(OUT_PIN,HIGH);
13   delay(1000);
14 }
```



0.000 Hz 0.000 Hz

Note: Optocoupler is better than Diode in safety

#### **2- DC Motors:**

Rotary electrical motors that converts (DC) electrical energy into mechanical energy, most types rely on the forces produced by magnetic fields.

Rotate directly when DC voltage applied, As the input current increase rotation speed increase, no way to make a precise rotation angle by applying the power for a certain time

Brushed	Brushless
Simple to operate.	High efficiency.
Reliable.	Longer life.
Available in many sizes and ratings.	Less maintenance.
Easy controls.	Better suited to continuous or long-
Good on lower duty cycles	running duty cycles.
Less efficiency.	Precise speed control.
Shorter life span.	Requires electronic controller.
Requires more maintenance.	More expensive.
	More complex .

# DC-Motor (Speed-Control) Example

```
4 #define OUT_PIN 3 PWM to control the Speed of Motor
 5 void setup() {
     pinMode(OUT_PIN,OUTPUT);
     analogWrite(OUT_PIN,0); initally Zero Value
 8 }
 9 void loop() {
         analogWrite(OUT_PIN,100);
                                                                                       0.000 Hz
                                                                                                                    0.000 Hz
10
                                                   Arduino Uno-4
11
        delay(1000);
                                                                                                                    0.000 Hz
                                                                                       0.000 Hz
12
         analogWrite(OUT_PIN,200);
                                                                                       0.000 Hz
                                                                                                                    0.000 Hz
13
        delay(1000);
14 }
15
```



#### 3- H-Bridge:

it switches the polarity of a voltage applied to a load.

used in robotics and other applications to allow DC motors to run forwards or backwards.

its name is derived from its common schematic diagram representation, with four switching elements configured as the branches of a letter "H" and the load connected as the cross-bar.


to build an H-bridge is to use an array of relays from a relay board

A "double pole double throw" (DPDT) relay can achieve same electrical functionality as an H-bridge (considering the usual function of the device).

a semiconductor-based H-bridge would be preferable to the relay where a smaller physical size, high speed switching, or low driving voltage (or low driving power) is needed, or where the wearing out of mechanical parts is undesirable

### DC-Motor (Speed-Control/Direction) Example

```
#define A_OUT_PIN 9
                         PWM Pins
 2 #define B_OUT_PIN 10
 4 void setup() {
    pinMode(A_OUT_PIN,OUTPUT);
    pinMode(B_OUT_PIN,OUTPUT);
    analogWrite(A_OUT_PIN,0);
    analogWrite(B_OUT_PIN,0);
 9
10
11 void loop() {
12
       analogWrite(A_OUT_PIN,200);
13
       digitalWrite(B_OUT_PIN,LOW);
       delay(3000);
15
       digitalWrite(A_OUT_PIN,LOW);
16
       analogWrite(B_OUT_PIN,200);
17
       delay(3000);
18
       analogWrite(A_OUT_PIN,100);
19
       digitalWrite(B_OUT_PIN,0);
20
       delay(3000);
21
       digitalWrite(A_OUT_PIN,0);
22
       analogWrite(B_OUT_PIN,100);
23
       delay(3000);
24 }
25
```



#### 4 - Servo Motors:

uses internal feedback system to go directly to the required angle.

controlled by a PWM input.

pulse width vary between minimum and maximum pulse width to produce


minimum and maximum deviation angle.

#### Typical values:


Min Pulse width:  $1 \text{ms} \rightarrow 0$  degree

Max Pulse width:  $2ms \rightarrow 180$  degree

PWM duty cycle: 20ms




### PWM Angle Control



### Servo Motors (Example)

```
1 #include <Servo.h>
                      Any name
3 Servo myservo;
4 // create servo object to control a servo
5 // twelve servo objects can be created on most boards
               // variable to store the servo position
 7 int pos = 0:
9 void setup() {
   myservo.attach(9); // attaches the servo on pin 9 to the servo object
11 }
13 void loop() {
   for (pos = 0; pos <= 180; pos += 1) { // goes from 0 degrees to 180 degrees
     // in steps of 1 degree
     myservo.write(pos); // tell servo to go to position in variable 'pos'
     delay(15); similar as digitalWrite // waits 15ms for the servo to reach the position
   for (pos = 180; pos >= 0; pos -= 1) { // goes from 180 degrees to 0 degrees
     myservo.write(pos); // tell servo to go to position in variable 'pos'
     delay(15);
                          // waits 15ms for the servo to reach the position
```



#### **5 - Stepper Motors:**

Provide precise angular steps with fixed value.

It has 2 types: Uni-Polar Model & Bi-Polar Model

Bi-polar is used to obtain the highest possible torque from the motor


Animation of a simplified stepper motor (unipolar)

Frame 1: The top electromagnet (1) is turned on, attracting the nearest teeth of the gear-shaped iron rotor. With the teeth aligned to electromagnet 1, they will be slightly offset from right electromagnet (2).

**Frame 2:** The top electromagnet (1) is turned off, and the right electromagnet (2) is energized, pulling the teeth into alignment with it. This results in a rotation of 3.6° in this example.

**Frame 3:** The bottom electromagnet (3) is energized; another 3.6° rotation occurs.

**Frame 4:** The left electromagnet (4) is energized, rotating again by 3.6°. When the top electromagnet (1) is again enabled, the rotor will have rotated by one tooth position; since there are 25 teeth, it will take 100 steps to make a full rotation in this example.



### Stepper Motor (unipolar/bipolar Example) (non-practical diagram)

```
1 #include <stdio.h>
 2 #include <stdlib.h>
 4 #define INP_PIN 2
 6 #define Bn_OUT_PIN 3
 7 #define An_OUT_PIN 4
 8 #define Bp_OUT_PIN 5
 9 #define Ap_OUT_PIN 6
11 #define A_OUT_PIN 3
12 #define B_OUT_PIN 4
13 #define C_OUT_PIN 5
14 #define D_OUT_PIN 6
16 #define DELAY 1000
18 #define V1 HIGH
19 #define V2 LOW
21 //#define V1 LOW
22 //#define V2 HIGH
24 void setup() {
     pinMode(INP_PIN,INPUT_PULLUP);
     pinMode(A_OUT_PIN,OUTPUT);
     pinMode(B_OUT_PIN.OUTPUT);
     pinMode(C_OUT_PIN,OUTPUT);
     pinMode(D_OUT_PIN,OUTPUT);
     digitalWrite(A_OUT_PIN,V1);
     digitalWrite(B_OUT_PIN,V1);
     digitalWrite(C_OUT_PIN,V2);
     digitalWrite(D_OUT_PIN,V2);
35 }
```

#### Unipolar Function

```
37 void unipolar driver()
38 {
        digitalWrite(A_OUT_PIN,V1);
        delay(DELAY);
        digitalWrite(A_OUT_PIN,V2);
        digitalWrite(B_OUT_PIN,V1);
        delay(DELAY);
        digitalWrite(B_OUT_PIN,V2);
        digitalWrite(C_OUT_PIN,V1);
50
        delay(DELAY);
51
52
        digitalWrite(C_OUT_PIN, V2);
53
        digitalWrite(D_OUT_PIN,V1);
55
        delay(DELAY);
56
57
        digitalWrite(D_OUT_PIN,V2);
58 }
```

```
Bipolar Function
62 void bipolar_driver()
63 {
       digitalWrite(A_OUT_PIN,V1);
       digitalWrite(B_OUT_PIN,V1);
       delay(DELAY):
       digitalWrite(A_OUT_PIN,V2);
       digitalWrite(C_OUT_PIN,V1);
       delay(DELAY);
       digitalWrite(B OUT PIN.V2);
       digitalWrite(D_OUT_PIN,V1);
       delay(DELAY):
       digitalWrite(C_OUT_PIN,V2);
       digitalWrite(A_OUT_PIN,V1);
       delay(DELAY);
       digitalWrite(D_OUT_PIN.V2);
88 void loop() {
90 unipolar_driver():
91 //bipolar_driver();
```

