


https://www.onda-it.com/eng/products/shell-and-tube-heat-exchangers

Equações gerais.

$$q = mg Cp, q(Tq, ent-Tq, sai)$$
 $q = mf(if sai-if, ent)$


$$e = 1 - exp(-NUT) \sim 7 ágla$$

 $E = 2 1 + C_V + (1 + C_V^2)^{1/2} \times 1 + \exp[-\sqrt{VT} (1 + C_V^2)^2]$ 1 - exp[-NVT (1+ Cr



Volumes de controle IV, V, VI: P/todos temos que Nvo; e => métado de Kern 7 he = Cte $\begin{array}{c|c}
T_{q,sai} = T_{q,ent} - m_{t}(i_{f,sai} - i_{f,ent}) \\
\hline
U_{1} = I_{1} + Rd, + V. M In (de/di) + (di) Rde + di In (de/di) \\
\hline
h_{i} = I_{1} + Rd, + V. M In (de/di) + (di) Rde + di In (de/de/di)
\end{array}$ Será nescessavie o uso de uma relação de E(NVI) p/ Cada zona, portanto temos que; Nolume de controle 11. Método da ejetividade Cz = mz cpiq / Cmin

Cz = m; cp; ji iq / Cmin 9 max = Cmin (Tq.ent - TJ.ent)



Volume de cantrole V Método da ejetividade Cq= mg cpiq = Cmin Cf -> 00 = Cmax

Método da ejetividade Cg= rng cpiq = Cmin Cf -> 00 = C mark NUT interno. Cr >0 $NUT_{i}=-\ln(1-\varepsilon)$ NUTi = UiAi - VA

Cq

Cq MUT externo: ~p/ casea com 1 passe E=2/1+Cr+(1+Cr2)1/2×1+exp-NUT(1+Cr)/2/1 1 - exp[-NUT (1+ Cr)]2 [NUTe = Ve Ae Volumes de controle IV, VI: P/todos 7 em 9 que Nuo; e => método de Kern $V = V_{IV} + V_{\overline{U}} + V_{\overline{VL}}$

$$NUT = U_i A_i = U_i D_i i L ...$$

$$C_{min}$$

$$L = NUT \cdot C_{min}$$

$$U_i D_i i i$$

$$Q_6 = N_i (T_{sai} - T_{ent})$$

$$T_{sai} = T_{sai} - T_{ent}$$

$$N_i = T_{sai} - T_{ent}$$