
COUNT_W = 16
clk
rst
enable
clear
threshold [8]
s_axis (interface)
count
m_axis (interface)