

Before operating the welding machine, ensure the grounding cable is securely attached to the workpiece. The welder must wear a protective shield to prevent flash burns from the electric arc. Inspect the pipeline for any signs of corrosion or leakage before starting the repair. Adjust the voltage and wire feed speed according to the thickness of the metal.