HVAC CX-40 Service Manual

1. Unit specifications

The CX-40 rooftop unit uses R-410A refrigerant.

The factory refrigerant charge is 2.4 kg.

The supply airflow is 1200 CFM.

The return air filter is MERV 13.

2. Preventive maintenance

Replace the air filter every 3 months.

Clean the evaporator coil every 6 months.

Flush the condensate drain every 3 months.

Check the refrigerant pressure in both heating and cooling seasons.

3. Error codes and reset

E1 means high-pressure lockout. Check condenser airflow and the outdoor fan.

E2 means low-pressure lockout. Check refrigerant charge and evaporator airflow.

E3 means sensor fault. Replace the discharge temperature sensor.

To reset the unit, turn the thermostat off for 30 seconds, then back on.