Lockout Tagout Procedure

1. Scope and personal protective equipment

This procedure applies to equipment energized at 50 volts or more.

Required PPE: arc-rated face shield, voltage-rated gloves, safety glasses, and flame-resistant clothing.

Only authorized employees may apply locks and tags.

2. Lockout sequence and inspection

Steps: notify affected employees, shut down the equipment, isolate all energy sources, apply locks and tags, release stored energy, and verify zero energy.

Try to start the equipment after lockout to verify isolation.

Remove locks only by the employee who applied them.

Inspect the lockout procedure annually.