

WORK PROCEDURE

PRO-OP-ITH-012A

PROCEDURE OF ITH REMOTE DRILLING

OBJECTIVE

The objective of this procedure is to define the safe methods for remote drilling with ITH drill

APPLICATION

This procedure applies to all employees of MACHINES ROGER INTERNATIONAL (MRI) as well as to the client's engineering department. Remote drilling should be decided by the client's engineering department based on the hazards that may be present while drilling. The driller or MRI supervision are invited to propose remote drilling if they consider it safer than conventional drilling.

Article 440 of the **QUÉBEC** Regulation respecting Occupational Health and Safety in Mines provides:

440. Notwithstanding section 439, holes may be drilled at distances less than those prescribed by that section provided that the drilling is carried out by a remote control device, under supervision, and that the drilling zone is evacuated.

NOTE: We apply the rules of Quebec unless the one that applies on the site is more severe

This procedure provides a framework for remote drilling work.

INTERPRETATION

The personnel having authority for the interpretation of this document is the director of operations. Any request for modification, revision or update must be made to this person.

RESPONSABILITIES

DRILLER

The driller must apply the remote drilling procedure according to the requirements proposed by the client. He must respect all the procedures surrounding drilling with ITH drill or any other equipment. This procedure is the minimum requested by Machines Roger International.

PROCEDURE OF ITH REMOTE DRILLING

MRI SUPERVISOR

The MRI supervisor must ensure the application of this procedure as well as compliance with the customer's engineering plan and specifications. He must also participate in any risk analysis requested by MRI or by the client.

CUSTOMER'S ENGINEERING DEPARTMENT

The engineering responsible for drilling must issue drilling plans and specifications remotely. These plans and specifications must take into consideration the risks associated with this type of drilling. The customer's engineering must be the initiator, if a risk analysis is necessary, or at least participate in this risk analysis.

MINE OPERATIONS

The mine operations department must require the application of this procedure. He must also participate in the implementation of work in collaboration with MRI and geology, in addition to participating in any risk analysis


PROCEDURE

1. Install the drill above the hole to be drilled according to the drilling plans and specifications
2. Install the system at a distance between the driller and the hole to be drilled at a minimum of 50' (15 meters):
 - a. The driller and the helper driller must be towards the exit, making sure that nothing is blocking access
 - b. Not be in the blast line, or
 - c. Some customers might also require to be behind protection such as:
 - i. A gallery perpendicular to the one where the drill is installed
 - ii. An equipment
 - iii. A pile of rock
3. All access to the drilling sites (driller and driller) must be barricaded by a fence or a ribbon (according to customer requirements/procedures) or guarded by a worker
4. Signage indicating the type of work (e.g.: PROHIBITED ACCESS, DRILLING IN PROGRESS, REMOTE DRILLING.) must be posted on the fence or the ribbon.
5. This procedure must be put in a waterproof bag on the fences of all accesses and signed by the driller who will have visited these places before the start of drilling, at the start of each work shift.
6. If a visit to the drilling site is necessary, the operator must be contacted by radio, or if visual contact is possible, the driller will move to meet the person(s) wishing to visit the site.

PROCEDURE OF ITH REMOTE DRILLING

7. The driller and the driller's helper will remain in the safe zone at all times while drilling.
8. When unblocking the driller must be attentive to the material coming out of the hole and if he finds that there is the presence of explosives, the operation with the drill must be stopped and the supervisor must be notified for the rest. Works.
9. When unblocking a blasted hole with amex (ANFO), water must be put in the drill rods to reduce the risk of explosion.

Modifications	by	Date
Add the article 440	S. Tremblay	18-11-2022
Add points #8 et #9	S. Tremblay	18-11-2022
Add NOTE about Quebec regulation	S. Tremblay	2-12-2022
Translation revision	S. Tremblay D. Baribeault	23-04-2024



Christian St-Amour
Operations Manager

PROCEDURE OF ITH REMOTE DRILLING

FEUILLE DE SIGNATURES DES BARRICADES LORS DU FORAGE À DISTANCE

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

Driller's signature :
Name (script letters) _____ Signature : _____

Date : _____ Night ☐ Day ☐ Time : _____ : _____

PROCEDURE OF ITH REMOTE DRILLING

Driller's signature :

Name (script letters) _____ Signature : _____

Date : _____ Night Day Time : _____ : _____