DRYCAL OPERATION

DAILY MAINTENANCE (OR EVERY 50 SAMPLES)

1. Using dishwashing detergent and a brush, scrub the bomb, bombcap and electrode assembly and rinse under a tap. NB. Do **NOT** immerse the bomb in water.
2. Using a blade, cut off the 2-002 O-Ring on the Valvepin and fit a lightly greased new seal.
3. Carefully inspect the 2-221 O-Ring on the bombcap, and replace as shown in the manual if there is any sign of damage or charing on it. Lightly grease the 2-221 O-Ring, wiping off any excess.
4. Unscrew the knurled nuts holding the firing wire in place and remove the wire. Clean off any corrosion with water paper, and fit a new wire.
5. Rinse and re-fill the Bombcap Cooler vessel with clean water.

OPERATION

1. Use only the supplied dome shaped crucibles.
2. For coal and Benzoic Acid, use a mass of 0.5 grams.
3. NB. The loaded bombcap must be carefully lowered smoothly into the bomb, using a slight rocking action so to prevent coal from being spilt into the bomb.
4. At the conclusion of the determination, always look down into the bomb to check that no coal was spilt. If this is seen to have happened the result must be discarded and the sample repeated.

NEVER IMMERSE THE BOMBS IN WATER

USE ONLY COTTON. NOT POLYESTER

WARNING

A BADLY MAINTAINED CALORIMETER IS A MAJOR HAZARD

USE ONLY SILICONE GREASE ON SEALS.