
STANDARD OPERATING PROCEDURE OF Knot Slip Resistance VF-B23

Lab /SOP/ 12




1. Tensile testing machine with chart recorder
2. Clamps
3. Steel scale or calipers
4. 5kg weight




Test six (6) samples
Tie a slipknot in the lace. There should be two ends of the lace in the knot that do not slip when pulled.




Attach the 5.0 kg weight to one end. Holding the other end, suspend the weight for a period of 10 seconds.



Once the lace has been set, place one fixed end and the sliding end into the clamps or pneumatic grips.



Set the speed on the tensile tester to 100 mm/min.



Pull the knot open and record the maximum force required to initiate knot slip.
Average maximum force to initiate knot resistance : kgf

Prepared by	Approved by	REVISION		DATE	