## STANDARD OPERATING PROCEDURE OF WHOLE SHOE WATERPROOF FLEX VF-G04

Lab /SOP/42



Shoe Flexing Waterproof Tester
Masking tape ( (½" wide)
PE plastic
Wire detector
Wire mesh



Draw flexing line according fingure 1



Set the flexing angle at 30 degree.
Set the flexes per minute between 70 ±10
Reset automatic counter to zero.



Put the shoe in the machine.
Set the distance between the toe cap clamp and the heel clamp in accordance with the size of the shoe selected.
Clamp at the heel.



Insert two ends of the conducting pins into the corresponding jacks, and then connect two other ends to the wire mesh inside the toecap.



Fill the container with water at normal temperature and adjust the level as specified per style.
Should use a colored water such as red, blue, or black help identify the point of water penetration.



Press the "Start Button "to initiate the testing but be sure that the BUZZER button is pressed before pressing the START BUTTON.



Inspect any presence of water. Wipe with white tissue paper on the edges to double check any penetration of water.
If leak(s) are detected cut with knife along the bonding position of the shoe and observe the position and extent of water penetration.
Record the number of cycles at which the water penetrated.

| Prepared by | Approved by | REVISION | | DATE | |
|---|---|---|---|---|---|