





School of Computer Engineering

Follow the steps for the below errors.



1. Check if the SW2 Switch  is **ON** & jumpers  are shorted (**JP3, JP6**)
2. **Switch off the kit** and then change the USB port -> Look for the port number in device manager -> change the COM port in flash magic.
3. Go to “Options” -> Advanced Options -> Mark “High Speed Communications” and change the Baud rate to **115200** (Preferrable) -> Click **OK**
4. **SWITCH ON THE KIT AND CLICK “Start”**
5. For the above errors you can also try switching **OFF** the kit and changing the baud rate to 7200 and then switching **ON** the kit.
 - Sometimes it works on 7200 & 9600 for both erasing and downloading
 - If you change settings in advanced options, then it'll affect “erasing and downloading”
6. **Clear the flash after every download.**

 Always **TURN OFF** the kit and make necessary connections/changes (while browsing for the hex file as well)

If the above steps don't work, troubleshoot it by following the below steps.

1. Changing the **USB** cable
2. Changing the **RS232** cable
3. Changing the **Power supply**

If none of the above works, **only then change the KIT**