

Workmanship Standards for Cable Accessories

Quality Team — TAQA Distribution

TAQA
DISTRIBUTION

REFERENCE NO.	REVISION	LAST UPDATED	CLASSIFICATION
QT-PTS-QA-002	1.0	28 Jun 2026	Internal

What "good" looks like for LV and MV joints and terminations. These are the workmanship expectations the Quality Team checks against — build them into every job.

CLEANLINESS

- Work in a clean, dry, enclosed environment.
- Keep insulation and adhesive surfaces free of dust, oil and moisture.
- Keep accessory packaging closed until the moment of use.

TOOLING

- Use the correct crimp tool and die for the connector.
- Use calibrated tools where calibration is required.
- Cut and strip with controlled, sharp tools — no nicks.

PREPARATION

- Set out preparation dimensions per the manufacturer instruction.
- Make clean screen breaks; no damage to the conductor.

INSULATION & STRESS CONTROL

- Build up insulation void-free with correct overlaps.
- Position stress-control components exactly as specified.

CONNECTORS

- Correct connector size for the conductor.
- Correct crimp count; check alignment and inter-phase spacing.

EARTHING & BONDING

- Maintain metallic screen continuity across the joint.
- Bond and earth screens / armour as specified.

IDENTIFICATION & RECORDS

- Apply phase identification.
- Record joint position and take photographs at key stages.

Remember: Acceptance rule: any item marked "No" on the inspection checklist is a non-conformance and must be closed out before the activity is accepted.