

Workmanship Standards for Cable Accessories

Power Quality Team · TAQA Distribution

TAQA
DISTRIBUTION

REFERENCE NO.	REVISION	LAST UPDATED	CLASSIFICATION
QT-PTS-QA-002	1.0	28 Jun 2026	Internal

What "good" looks like for LV and MV joints and terminations. These are the workmanship expectations the Power Quality Team checks against. Build them into every job.

CLEANLINESS

- Work in a clean, dry, enclosed environment.
- Keep insulation and adhesive surfaces free of dust, oil and moisture.
- Keep accessory packaging closed until the moment of use.

TOOLING

- Use the correct crimp tool and die for the connector.
- Use calibrated tools where calibration is required.
- Cut and strip with controlled, sharp tools; no nicks.

PREPARATION

- Set out preparation dimensions per the manufacturer instruction.
- Make clean screen breaks; no damage to the conductor.

INSULATION & STRESS CONTROL

- Build up insulation void-free with correct overlaps.
- Position stress-control components exactly as specified.

CONNECTORS

- Correct connector size for the conductor.
- Correct crimp count; check alignment and inter-phase spacing.

EARTHING & BONDING

- Maintain metallic screen continuity across the joint.
- Bond and earth screens / armour as specified.

IDENTIFICATION & RECORDS

- Apply phase identification.
- Record joint position and take photographs at key stages.

Remember: Acceptance rule: any item marked "No" on the inspection checklist is a non-conformance and must be closed out before the activity is accepted.