14. 3Ø phase Line voltage (V_L) V-voltage L-line	$V_L=V_{RY}=V_{YB}=V_{RB}$ Voltage between any two phases of the system.
15. Line current (I_L) I=current L=line	$I_L=I_R=I_Y=I_B$
16. Phase voltage (V_p) V=Voltage P=Phase	Voltage between any one of the phases and the NEUTRAL terminal
17. Phase current (I_p) I=current P=phase	Current flowing through anyone of phase winding is called as phase current.
18. Delta system RYB system	$V_L=V_P=V_{PY}=V_{YB}=V_{RB}$ $I_P=I_R=I_Y=I_B$ $I_P=I_L\sqrt{3}$
19. Star system RYNB system	$I_P=I_L=I_R=I_Y=I_B$ $V_P=V_L\sqrt{3}$ $V_{RN}=V_{YN}=V_{BN}=V_P$
20. Direct on line starter (DOL starter)	Used for motors with capacity up to 5 Hp.
21. Star-delta starter	Used for motors with capacity 5Hp to 15 Hp.
22. Auto transformer starter	Used for motors of capacity more than 15 Hp.
23. Rotor resistance starter	a. Full line voltage is applied across starter windings b. Full value additional resistance is added in series with each phase of the rotor windings c. These resistance are immersed in oil.
24. 1 H.P	746 wattes
One horse power	0.746 kilo wattes.

GM_Chp10.indd 140 14-02-2019 11:46:22