


Fig. 6.36. AutoCAD 2016 - Status Bar




Fig. 6.37. AutoCAD 2016 - Application

Drawing Coordinates

By default this button is hidden in AutoCAD 2016. Using the Customization menu you can show it. It displays the drawing coordinates when you move the pointer in the drawing area. You can also turn OFF this button by clicking on it.

XII CompTech_English version CHAPTER 06.indd 182 10-04-2019 11:04:30