

starting to assemble the PC, consider every place where you'll be putting a component and the paths of all the cables. If you think a component would restrict flow of the cable of another component, fit that other component and its cable first. Same goes for vice versa.

Cases usually have routing holes on one side. Use them to tuck away the cables behind prying eyes. Make sure that the thicker cables don't overlap each other. You should try to make the cabling as flat and spread apart as possible. After flattening, in case a cable or two gets excess remaining, instead of rerouting that cable to spread more, coil it and place it in a corner. Putting the coil in a corner will keep it away from getting into a mess with other cables. Use ties to hold together the cables which have to travel together. Often times there would be openings which would allow you to lock your ties to a spot. If they aren't present, use tie mounts. Bear in mind that you might have to change or move some cables more often than others. Use simple cable ties for those you wouldn't be changing often and twist ties or any reusable alternative, for those you'd be changing often. Each cable should be running through the holes closest to its connectors. And don't forget to leave a little slack in the cables near the connectors so that they don't



An example of an average attempt at cable management