

► **Problem:** Your USB DVD-Writer fails to write at its maximum rated speed, even when you use media certified for the maximum rated speed of the writer.

Cause: The USB DVD-Writer is USB 2.0 compliant while the port is an older version.

Solution: Check if the motherboard supports USB 2.0. If not, the speed bottleneck may be the cause of your problem. If your motherboard supports USB 2.0, then check if it is enabled, and set it to USB 2.0 mode in the BIOS.

► **Problem:** When you disconnect a USB device from your PC and reconnect it later, duplicate names of the device appear in the Device Manager.

Cause: The firmware of the USB device is corrupt.

Solution: Download the latest firmware for the USB device from the manufacturer's Web site and upgrade your device.

► **Problem:** You have a FireWire DV Camcorder. After installing Service Pack 2 on Windows XP Professional, the performance of the FireWire has decreased, and your capture application reports dropped frames every now and then.

Cause: This is a known issue with Windows XP Service Pack 2.

Solution: There is an update available on the Microsoft

