



Fig. 1: Attributes gschem



Fig. 2: PCB tool library

[DIP18] highlighted by the green box in Fig. 2. As you gain experience with this tool, you will remember these names and will not need to simultaneously keep the PCB tool open every time you work on gschem.

7. Sometimes, footprint names are too complex to remember. In that case, you can name the footprints in ways that you can remember. In our case, we



Fig. 3: Toolbar PCB tool

Take care, sudo is a must.

Use the copy command if you wish to keep the original also.

In this manner, you can simplify the names so that you can enter the component without using the PCB tool in parallel.

There are several people contributing their symbol and footprint libraries, so you don't have to make them yourself. Whenever you need a part which is not there, do check <http://www.gedasymbols.org/>

To use these symbols and libraries, just download them and put them in the corresponding directories as mentioned above.

completely changed the nameS of the footprints and gave them simple names.

8. You can simply change the footprint names as follows:

All the footprints are at the location 'usr/share/pcb.'

Go to the folder where you want to change the name of the footprint.

Rename them using the move command: 'sudo mv filename Newfilename.'

The complete documentation of gEDA is available at <http://wiki.geda-project.org/geda:documentation>. The documentation has improved a lot over time and almost all the sections are addressed properly.

To create your own footprints, follow the steps given below:

1. Run the PCB tool and set the grid.
2. Use the datasheet for the correct dimensions of the footprint corresponding to each element.
3. Now use Via and line (selecting the silk layer) to draw the footprint as per the dimensions in the datasheet.
4. Take care for correct dimensions of hole (drill), pitch, and other dimensions (reference is the grid)
5. Once the footprint is drawn select it completely using the drag of the mouse.
6. Now click on 'cut selection to buffer' in Buffer menu at the top
8. Click at the centre of the drawn footprint (this will define the origin)
8. Click on 'convert buffer to element' option. This will make you drawn footprint as one part.
9. Now the final step is to click on the option 'save buffer element to file' and give proper naming to your footprint.
10. You have your footprint ready the only thing left is to transfer it to the right directory which is already explained above.

Read more
stories on
Power Electronics
at

www.electronicb2b.com

Top Battery Stories

- ❑ Electronics in power sector: Challenges & opportunities
- ❑ The latest in home UPS systems
- ❑ The latest in industrial inverters
- ❑ UPS and inverter market evoked mixed response in 2012-13. While it was smooth sailing for the giants, SMEs found the going tough
- ❑ Industrial UPS systems are becoming highly customised
- ❑ The latest in switch mode power supplies

ELECTRONICS

B2B
INDUSTRY IS AT A

CLICK OF A BUTTON

Log on to www.electronicb2b.com and be in touch with the Electronics B2B Fraternity 24x7