

MW-A-001 ASSEMBLY WORK INSTRUCTION

1. Controlled inputs and preparation

Assembly: MW-A-001 – Magic Wand Assembly

Coordinate basis: MODEL_XYZ; all positions are row-major transforms in millimetres.

Verify every part number and revision against the hash-bound BOM before handling components.

Inspect molded parts for flash, short shot, sink, warp and blocked controlled openings.

Protect RF keep-out surfaces from metallic pigment, conductive coating and loose hardware.

ITEM 01: MW-M-001A REV B-RFQ QTY 1

ITEM 02: MW-M-001B REV B-RFQ QTY 1

ITEM 03: MW-M-002 REV B-RFQ QTY 1

ITEM 04: MW-M-003 REV B-RFQ QTY 1

ITEM 05: MW-M-004 REV B-RFQ QTY 1

ITEM 06: MW-M-005 REV B-RFQ QTY 1

ITEM 07: MW-P-001 REV B-RFQ QTY 1

MW-A-001 ASSEMBLY WORK INSTRUCTION

2. Assembly sequence and verification

Stage all components at the released MODEL_XYZ transforms; do not infer offsets from page graphics.

Fit locating interfaces by hand without forcing; stop on hard bind, visible stress whitening or incomplete seating.

Apply only drawing-controlled fastening, adhesive or welding operations. Record supplier series and lot in the traveler.

After closure, perform the exact interference/clearance audit and retain the machine log with this revision.

Complete final visual, dimensional and functional inspection before engineering review sign-off.

Wand order: carrier into lower shell; rear cap and connector locate; GFRP seats in adhesive bore; plunger enters guard relief; upper shell closes last.

Ultrasonic energy directors are intentional process interference and require a weld DOE before production use.