MAINTENANCE TECHNICAL SUPPORT CENTER **HEADQUARTERS MAINTENANCE OPERATIONS**





Maintenance Management Order

SUBJECT: Preventive Maintenance Guidelines for

Overhead Scanning Solution Tracking System for Model 89 Conveyor (OSSTS)

TO: All Overhead Scanning Solution Tracking

System Model 89 Sites

DATE: June 14, 2012

> MMO-073-12 NO:

FILE CODE: R7

dtod:mm10034ab

This MMO provides Preventive Maintenance (PM) guidelines for the Overhead Scanning Solution Tracking System for Model 89 Conveyor. The eMARS acronym is OSSTS. Class code is AB.

The minimum maintenance skill level to perform each task on the various checklists is included in the Minimum Skill Level column. This does not preclude higher level employees from performing any of this work.

The work hours represented in this MMO reflect the maximum work hours required to maintain the equipment. Given local conditions, management may modify task frequencies.

WARNING

Various products requiring Material Safety Data Sheets (MSDS) may be utilized during the performance of the procedures in this bulletin. Ensure the current MSDS for each product used is on file and available to all employees. When reordering such a product, it is suggested that current MSDS be requested. Refer to MSDS for appropriate personal protective equipment.

WARNING

The use of compressed or blown air is prohibited. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used only on optical equipment when other cleaning methods can not be used.

Web Access: https://www1.mtsc.usps.gov

Maintenance Managers are to use these preventive maintenance guidelines when preparing the route sheets for local maintenance personnel. It is the responsibility of each Maintenance Manager to ensure all WARNINGS, CAUTIONS, and NOTES are included with each applicable task as part of the preparation of any local route sheets.

For questions or comments concerning this bulletin contact the MTSC HelpDesk, either online at MTSC>HELPDESK>Create/Update Tickets or call (800) 366-4123.

Robert E. Albert

Manager

Maintenance Technical Support Center

HQ Maintenance Operations

Attachments:

1. Summary Workload Estimate for OSSTS

2. OSSTS Master Checklist: 03-OSSTS-AB-001-M: Weekly

3. OSSTS Master Checklist: 03-OSSTS-AB-002-M: Monthly

ATTACHMENT 1

SUMMARY

WORKLOAD ESTIMATE

FOR

OSSTS

SUMMARY WORKLOAD ESTIMATE FOR OSSTS

Days	Routine Servicing (hrs/yr)	Repair* (hrs/yr)	Total Servicing & Repair Time (hrs/yr)	Nonproductive Time** (hrs/yr)	Total Servicing Per Machine (hrs/yr)
5 Day	19.93	5.98	25.91	2.59	28.50
6 Day	19.93	5.98	25.91	2.59	28.50
7 Day	19.93	5.98	25.91	2.59	28.50

^{*} Repair Estimates based on 30%.
** Based on 10.00% of total servicing and repair.

ATTACHMENT 2

OSSTS MASTER CHECKLIST

03-OSSTS-AB-001-M

WEEKLY

Time Total: 20 Minutes

U.S. Postal Service								IDE	NTIF	ICAT	ION					
Maintenance Checklist	_	RK DE			_		MEN NYN	-			CLA CO		N	JMBE	R	TYPE
	0	3	0	S	S	Т	S				Α	В	0	0	1	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmeı	nt Mo	del				В		n Filer M10	name 034AB	1 7	Occurr		eekly	/

	yOi						
Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	s
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
SAFETY STATEMENT	1.	COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shut down and lock out this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment. THE USE OF COMPRESSED OR BLOWN AIR	5	All			
		IS PROHIBITED. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods can not be used. Report safety deficiencies to your supervisor immediately upon detection.					
		WARNING Be cautious when working around or on equipment when power has been applied.					
		аррпец.					
POWER ON	2.	Power on. 1. Power on OSSTS Model 89 at power lockout box by rotating the disconnect switch clockwise to the ON position. If power lockout box does not supply system power, ensure that power cable connector is plugged into the facility supplied power drop. 2. Power on E-Box using power switch located on left side of E-Box. Listen for audible beep indicating power has been applied. If E-Box does not power on, check power cable connections and fuse.	1	All			

U.S. Posta	MODIC	1		· O I '''		IDENTIFICA		A C C		וואסככ	-	TVDE							
Maintenance	e Chec	klist	WORK CODE				MENT DNYM			LASS ODE	I NU	JMBER		TYPE					
			0 3	0 S	S	Т	S		Α	В	0	0 1	Veekly						
Equipment Nomenclatu Overhead Scar Tracking Systen Conve	nning So n for Mo		Equipme	nt Model				Bulletin Fil MM1	ename 0034Al	В	Occurre		кlу						
Part or	Item		Tack	Statemen	t and I	nstru	ction		Est.	Min.		Thresh	olde						
Component	No	(Comply wi					ns)	Time	Skill	-								
									Req (min)	Lev	Run Hours	Fed		Freq.					
				CAU	ΓΙΟΝ														
		refer into over aver encoused are haza	not starts to attend the lift riding of sion (look buntering of proper not contained that we have been scanner; see the power of LCD in laying the start of the laying the laying the start of the laying the laying the start of the laying the l	empts to ight of the nate ooking of a browning of a browning of a scanne of attern is lit. It is scan processed to cable to nonitor is e Operation.	o into it	enti s bli r) re lig lase be eye isible nina n is a scar vere ll Mo	onally ong nking eflex ht so a rad injur e Lase ted or not vishiner. d on a de* se	y look axis, and when ource. ducts iation ies. er Diode											
		swit	e LCD is ch, powe	er, and d	ata c	able	conn	ections.											
		upon bo	tional Mo ot up. In the MPE 'S.	this mod	de, th	ne so	reen	will											
E-BOX	3.	E-Box v	isual ch	eck.					0.5	7									
		1. EES If th sele swit acco	e EESS ect the co ch on left ess pane	x = chan channel orrect cha t side of el. and tim date or ti E-box, i	rang range annel E-bo e e me is f this	e is I usii ox be	incorrects not	to 008 ect, rotary small											

U.S. Postal Service								IDE	NTIF	ICAT	ION					
Maintenance Checklist		RK DE					NEM ONYN				CL/ CO	ASS DE	N	UMBI	ĒR	TYPE
	0	3	0	S	S	Т	S				Α	В	0	0	1	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmeı	nt Mo	del				В		n Filer M10	name 034AB		Occuri		eekly	/

Part or	Item	Task Statement and Instruction	Est.	Min.		Threshold	S
Component	No	(Comply with all current safety precautions)	Time Req	Skill Lev	Run	Pieces	Freq.
			(min)		Hours	Fed (000)	
		assistance.					
		3. DCS: CONNECTED					
		If DCS shows disconnected, check					
		connections for the network cable drop, the network cabling between the power lockout box and Ebox port J2 WAN.					
OVERHEAD SCANNERS	4.	Scanner alignment visual check.	1	7			
COANTERC		CAUTION					
		Do not stare into laser beam. This refers to attempts to intentionally look into the light on its long axis, overriding the natural blinking and aversion (looking away) reflex when encountering a bright light source. Used properly, Class II laser products are not considered to be a radiation hazard that would cause eye injuries.					
		Visually check each overhead scanner's scan pattern on conveyor belt to ensure the lower horizontal scan line in the scan pattern is positioned approximately three inches from edge of conveyor belt nearest operator's position.					
		Refer to MMO-029-10, Overhead Scanner Alignment for additional information and alignment procedures.					
E-SWITCH	5.	Start run.	0.5	7			
		 Press START/STOP button on E-Switch to begin a run. If START/STOP button on E-Switch does not begin and / or end a run, check the connections for the network cable between the E-switch and the network router. Power cycle the E-switch by disconnecting and reconnecting the power supply connector on top-side of E-switch. 					
		Check overhead LCD monitor for current date and time.					

U.S. Postal Service	IDENTIFICATION CONTROL OF THE PROPERTY OF THE															
Maintenance Checklist	CO	RK DE					MEN NYM				CLA CO		NI	JMBE	₽R	TYPE
	0	3	0	S	S	Т	S				Α	В	0	0	1	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmei	nt Moo	del				E		n Filer M100	name 034AB		Occurr		eekly	′

Part or Component	Item No	(0	Task Statement and Instruction Comply with all current safety precautions	s)	Est. Time Req	Min. Skill Lev	Run	Threshold Pieces	s Freq.
					(min)	201	Hours	Fed (000)	r ioq.
OVERHEAD	6.	Overhea	ad Scanner scan test.		5	7			
SCANNERS		scan tes	Barcode Test Mailpiece* to perfo t on each overhead scanner whil anal Mode.						
		* Refer t Preparat	o MMO-070-12 for Barcode Test tion.	Sheet					
		1. Sca	an Barcode Test Sheet 1 for Scar	nner 1.					
		a.	Ensure scanner responds with audible tone and green LED fla						
		b.	Check the LCD monitor for COI increment at P1.	UNTS					
		2. Sca	an Barcode Test Sheet 2 for Scar	nner 2.					
		a.	Ensure scanner responds with audible tone and green LED fla						
		b.	Check the LCD monitor for COI increment at P1.	UNTS					
		3. Sca	an Barcode Test Sheet 3 for Scar	nner 3.					
		a.	Ensure scanner responds with audible tone and green LED fla						
		b.	Check the LCD monitor for COI increment at P1.	UNTS					
		4. Sca	an Barcode Test Sheet 4 for Scar	nner 4.					
		a.	Ensure scanner responds with audible tone and green LED fla						
		b.	Check the LCD monitor for COI increment at P1.	UNTS					
		5. Sca	an Barcode Test Sheet 5 for Scar	nner 5.					
		a.	Ensure scanner responds with audible tone and green LED fla						

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	_	ORK ODE					MEN NYNC					ASS DE	N	UMBI	ĒR	TYPE
	0	3	0	S	S	Т	S				Α	В	0	0	1	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmer	nt Mo	del				E		n Filer M10	name 034AB		Occurr		eekly	/

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
HANDHELD SCANNERS	7.	 b. Check the LCD monitor for COUNTS increment at P1. 6. If the Overhead Scanner scan test fails, visually check the following system components for power by checking LED indicators for illumination: a. 8-Port Multiplexor MI8008 b. Ethernet Router c. Multipoint Access Hub MSP1000 If one or more of the components are not powered on, check the power cable connection between power source and component and power switch where applicable. If problem persists, contact MTSC for assistance. FocusBT handheld power on and scan test. Perform this procedure with each Focus BT handheld scanner using Barcode Test Sheet 6*. * Refer to MMO-070-12 for Barcode Test Sheet Preparation. Install charged battery, as necessary, into FocusBT handheld scanner and power on scanner using power button located at base of handle. Scan FocusBT Scanner Barcode #1 with handheld scanner #1. a. Verify scanner responds to scan with an audible tone and white LED flash.	5	7		(000)	
		 b. Check system LCD monitor for scan count increment at J1. 3. Scan FocusBT Scanner Barcode #2 with handheld scanner #2. 					

U.S. Postal Service	IDENTIFICATION OLAND ANAMED TO															
Maintenance Checklist		ORK ODE					MEN NYM				CLA CO	ASS DE	N	UMBI	ĒR	TYPE
	0	3	0	S	S	Т	S				Α	В	0	0	1	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipme	nt Mo	del				E		in Filei	name 034AB		Occuri		eekly	/

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
Component	140	(Comply with all current salety precautions)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.
		 a. Verify scanner responds to scan with an audible tone and white LED flash. b. Check system LCD monitor for scan count increment at J1. 4. Scan FocusBT Scanner Barcode #3 with handheld scanner #3. a. Verify scanner responds to scan with an audible tone and white LED flash. b. Check system LCD monitor for scan count increment at J1. 5. Scan FocusBT Scanner barcode #4 with handheld scanner #4. a. Verify scanner responds to scan with an audible tone and white LED flash. b. Check system LCD monitor for scan count increment at J1. 6. Power off each Focus BT handheld scanner at base of handle, remove and charge battery as necessary. 					
CLEAN UP	8.	Clean up. Ensure all tools and test pieces are removed from the work area and stored in a safe area for future use. Report all deficiencies to your supervisor.	2	All			

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	_	WORK CODE					MEN ONYM				CLASS CODE		NUMBER			TYPE
		3	O S S T S					Α	В	0	0	1	М			
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmer	nt Mo	del				В	Bulletin M l		name 034AB		Occurr		eekly	/

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill		Threshold	S
·		, ,	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.

THIS PAGE BLANK

ATTACHMENT 3

OSSTS MASTER CHECKLIST

03-OSSTS-AB-002-M

MONTHLY

Time Total: 13 Minutes

U.S. Postal Service	IDENTIFICATION															
Maintenance Checklist	dist CC			EQUIPMENT ACRONYM								CLASS CODE		UMBI	TYPE	
		3	0	S	S	Т	S				Α	В	0	0	2	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmeı	nt Mo	del				В		n Filei M10	name 034AB		Occuri		onthly	У

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Thresholds					
Compans		(comply min an outloadedy proceeding)	Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.			
SAFETY STATEMENT	1.	COMPLY WITH ALL SAFETY PRECAUTIONS. Disconnect power and apply lockouts when required by this instruction. Refer to current local lockout procedures to properly shut down and lock out this machine. Open equipment and inspect dust conditions. Check for suspicious dust or unusual debris. If any unusual substance is found notify supervisor prior to proceeding with any further action on the equipment.	5	All						
		THE USE OF COMPRESSED OR BLOWN AIR IS PROHIBITED. When cleaning is required, an alternative cleaning method such as a HEPA filtered vacuum cleaner or a damp rag must be used in place of compressed or blown air. A lint-free cloth or brush may be used on optical equipment only when other cleaning methods can not be used. Report safety deficiencies to your supervisor immediately upon detection.								
OSSTS	2.	Power down and lock out power. Power down and lock out the equipment as prescribed by local lockout/restore procedures.	1	All						
	3.	Overhead scanner lens cleaning. CAUTION Do not use solvents like alcohol or acetone to clean scanner lens. These materials can damage the camera scanning lens. Use a lint-free non-abrasive cleaning cloth to gently clean each Overhead Scanner lens and each Bluetooth Handheld Scanner lens.	5	7						
CLEAN UP	4.	Clean up. Ensure all tools and cleaning materials are removed from the machine and work area.	1	All						

U.S. Postal Service		IDENTIFICATION														
Maintenance Checklist		ORK ODE					MEN ONYM				CLASS CODE		NUMBER			TYPE
		3	0	S	S	Т	S				Α	В	0	0	2	М
Equipment Nomenclature Overhead Scanning Solution Tracking System for Model 89 Conveyor	Equ	ipmeı	nt Mo	del				В		n Filer M10	name 034AB		Occurr		nthly	/

Part or Component	Item No	Task Statement and Instruction (Comply with all current safety precautions)	Est. Time	Min. Skill	Thresholds					
·			Req (min)	Lev	Run Hours	Pieces Fed (000)	Freq.			
		WARNING								
		Be cautious when working around or on equipment when power has been applied.								
OSSTS	5.	Restore equipment to service.	1	All						
		Restore equipment to service as prescribed by local lockout/restore procedures.								