The state of the s	Toot Form 44/4/46)]]		DAZING DB
										b Meeting			
			JAK.		1	765	1-25	0-3-16					
					_	1/55	9:30	225-16		3 Setup 4 FAIR	100		
		Notes	Inspactor	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	ď	 Maintenance Tooling 			
			rt Inspection Record	First Part I			2 2	The second	e Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
													ROUTING:
	Ø												
		P	Z										
			20										
		9									=		
103													
									1				
							/			•	5		1 /1 /
	0						0	T		F)	1	70	1/2 <i>5/</i> 10
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cu	Total Pcs.	Prod Hrs.	Emp. Name	Date
	144	Thru- put/8hrs	18	Pcs./Hr	M	3 1	Cycle Time	30 MIN	Setup Hrs.	H2		Mach. No.	
					Secretary of		And the second		Section Section 1		AND RESOUR		
				ď.					ity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
- 65		e:						Lot Number.	wed by "I	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
							box label.	date on the	mber and	Use their work order number and date on the box label	Use their w	Flare Tubes	Flare
				18			etter "M."	ng with the le	el, startir	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
		Ī	びる	\sim		3	ord "heat."	above the w	l, directly	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
	5	CACTORAS	BRZ00				x quantity.	bel under bo	he box la	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flar
			CASC-11					mbers	ablity Nur	Distinguishing Traceablity Numbers	Disting		
		3	ASC-11							2		Order Qty	Ord
		No(s)	Component(s)	Cor		ררכ	devices, LLC			400707	40	Order No.	Ord
	ility	Heat Lot/Traceability		,			7		a.	ASC-11-7	AS	Part No.	Pai