Test Form 11/4/15	Test F)RD	BRAZING PRODUCTION RECORD	BRAZING PR
									Meeting	6 0		
									Setup FAIR			
	Notes		Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling			
			t Inspection Record	First Part Ir	ш	1000			Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
	Ø											
)											
		So pl										
		10,0										
	5											
			1									
									15		S6	12/2
Scrap	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8hrs		Pcs./Hr			Time	· ·	Hrs.		Mach. No.	
		Thru-			Constant of the last		Cycle	dp	Setup			
			2						traceability.	Do not require traceability.	Caps/Plugs	Сар
							•=	y "Lot Number	Located on the bag followed by "Lot Number."	Located on th	Snap Rings	Sna
							e box label.	ind date on the	Use their work order number and date on the box label.	Use their worl	Flare Tubes	Flare
							etter "M."	rting with the I	Located on the spool label, starting with the letter "M."	Located on th	Copper Tubing	Coppe
						230	word "heat."	tly above the v	Located on the box label, directly above the word "heat."	Located on th	Brazing Rings	Brazi
							ox quantity.	label under bo	Six digit no. located on the box label under box quantity.	Six digit no. lo	Flare Nuts	Flar
	20060667	3006	E-RING					lumbers	Distinguishing Traceablity Numbers	Distinguish		
	À	2/2	901-14-3/16	90						15	Order Qty	Ord
	No(s)	· Z	component(s)	Con		LLC	devices, LLC	C C	53	392253	Order No.	Ord
	Heat Lot/Traceability	Heat Lot/		,			7		/15-R	901-14-3/15-R	Part No.	Pa