4	
V	1
r	J

			Special Notes / Instructions	ROUTING:								3/36 58	Date Emp. Name	Mach. No.		Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	<b>Brazing Rings</b>	Flare Nuts		Order Qty	Orger No.		
			Instructions									0	lame Prod Hrs.	No.	Mental Mental	. Do no	Locat	Use t			Six di	D				
6	ω 4 τ	2											Hrs.		ne paggine	ot requ	ed on t	heir wo	ed on t	ed on t	git no.	istingu		40		
<ol> <li>Maintenance</li> <li>Tooling</li> <li>Setup</li> <li>FAIR</li> <li>Training</li> <li>Meeting</li> </ol>	Down Time (						_	Total Pcs.			Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	Þ	402074							
1994			Codes										Cur	Hrs.		1.	ed by "L	ber and	l, startin	directly	e box lak	lity Nun				
		Date Part Submitted											Cum. Total				ot Number.	date on the	g with the I	above the v	el under bo	bers				
		Time Of Day											Down Time	Cycle	Notice of the country		i a	box label.	letter "M."	vord "heat.'	ox quantity.			devices, LLC		
		Approved Yes / No											Down Time Code							=				LLC		
		Mtrl Check																								
		Rev Letter	First Part In											Pcs./Hr	A STATE STATE OF						ď	DC	2803			
		Inspector	Inspection Record				97	2							Notes		A A STATE OF THE STATE OF						A-KF003	DCN516-HT	2803-10-3/16-0	Component(s)
								Λ. <sup>^</sup>	)/14					Thru- put/8hrs								~	10			
		Notes											S								ZA	ZZ	HEOLOH	No(s)		
					7)								Scrap													
													Scrap Code													