			THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NAM				0			
	(artifula)	X	4	108	Rp.	(sd-16)	Setup FAIR Training Meeting	ω 4 v a		
	Notes	Inspector	Mtrl Check Rev Letter	Approved Yes / No	Time Of Day	Date Part Submitted	Maintenance Tooling	2		
		t Inspection Record	First Part				Down Time Codes	tions	Special Notes / Instructions	2
P			1							
										25
										$\perp$
	i,									
	2									
	1(0		1							
					B	S	330	<i>i</i> 0	20	
Scrap Scrap	10	Notes		Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	
	put/8hrs				Time				Section of the Stock of the Section	
	Thru-		Pcs./Hr	All the contract of the contra	Cycle	Setup	Ser		Mach. No.	
	3.						Do not require traceability.	Do not requi	Caps/Plugs	Sd
						y "Lot Number	Located on the bag followed by "Lot Number."	Located on t	-	ac
		CP13			e box label.	and date on th	Use their work order number and date on the box label.	Use their wo	Flare Tubes	re
		BRZ04	1		letter "M."	rting with the	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	pe
		BRZ01			word "heat."	ctly above the	Located on the box label, directly above the word "heat."	Located on t	_	Zir
_1		CUTU-14-3/16	C		ox quantity.	x label under b	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	ar
		CUTU-3-1/2				Numbers	Distinguishing Traceablity Numbers	Distingui		1
	2 6/7/162	SF4-3-3					100	1	Order Qty	g
	No(s)	Component(s)		LLC	devices, LLC		394495	39/	Order No.	ᇗ
	Heat Lot/Traceability		-		222722	J				