Test Form 11/4/15	Test Fo.									)RD	BRAZING PRODUCTION RECORD	BRAZING PRO
									FAIR Training	υ 4 π		
		Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted		2 2 1		
			First Part Inspection Record	First Part In			- N	S	Down Time Codes	tions	Special Notes / Instructions	Specia
												ROUTING:
												1
				1								
Scrap Code	Scrap		Notes			Down Time Code	Down Time	Cum. Total	Total Pcs.	Prod Hrs.	Emp. Name	Date
		put/8nrs			1		line	= 9.				
		Thru-		Pcs./Hr			Cycle	Setup	Se		Mach. No.	
		240							Do not require traceability.	Do not requi	Caps/Plugs	Caps
					L		·a	y "Lot Number	Located on the bag followed by "Lot Number."	Located on t		Snap
			CP15				e box label.	and date on the	Use their work order number and date on the box label.	Use their wo	Flare Tubes	Flare
			CUTU-0-7/8	2	<u> </u>		etter "M."	arting with the l	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
			BRZ05		L		vord "heat."	ctly above the v	Located on the box label, directly above the word "heat."	Located on t	Brazing Rings	Brazin
			BRZ09				ox quantity.	x label under bo	Six digit no. located on the box label under box quantity.	Six digit no. I	Flare Nuts	Flare
			CUTU-0-1/4	5				Numbers	Distinguishing Traceablity Numbers	Distingui		
			7-4-9						9		Order Qty	Orde
		No(s)	component(s)	Con		LLC	devices, LLC	1	391335	391	Order No.	Orde
	Ϊŧγ	Heat Lot/Traceability					2		S7-4-9-24-C	S7-4-	Part No.	Par
				101		1						