	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	ice	 Maintenance Tooling 			
THE REAL PROPERTY.		First Part Inspection Record	First Part In					ne Codes			Special Notes / Instructions	Specia
												ROUTING:
9												
Ş								Ī				
	7 77							+				
	<u> </u>											
	-											
			-									
	1											
									دو		SB	1/22
Scrap Scrap Code		Notes			Down Time Code	Down Time	Cum. Total	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
	put/8hrs		Pcs./Hr			Time		Hrs.			Mach. No.	
	There	THE RESERVE THE PERSON NAMED IN		Total March	No. of Contrast	Cycle	の一の一の一の一の一の一の一の一の一の一の一の一の一の一の一の一の一の一の一	Setun		CHARLE SAME A WALL		
	, P.							llity.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
		4		!		=	ot Number.	owed by "Lo	Located on the bag followed by "Lot Number."	Located on		Snap
						box label.	date on the	umber and	Use their work order number and date on the box label.	Use their w	Flare Tubes	Flare
			750			etter "M."	g with the I	bel, starting	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
						ord "heat."	above the v	el, directly a	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazin
						x quantity.	el under bo	the box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
	30060667	E-RING					bers	eablity Num	Distinguishing Traceablity Numbers	Distingu		
_1	2/4	ER10					1		2		Order Qty	Orde
	No(s)	component(s)	Con		רכ	devices, LLC	H		397822	39	Order No.	Orde
	Heat Lot/Traceability)			1			EKTO-K		Part NO.	Par