									THE PARTY OF THE P		
								<ul><li>5 Training</li><li>6 Meeting</li></ul>	0 15		
									- N		
	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted					
	First Part Inspection Record	First Part I					odes	Down Time Codes	tions	Special Notes / Instructions	Specia
											ROUTING:
								9		SB	16
	Notes			Down Time Code	Down Time	Cum. Total	Cun	Total Pcs.	Prod Hrs.	Emp. Name	Date
put/8hrs		Pcs./Hr			Time		Hrs.			Mach. No.	
Thrit					Cycle		Setup				
			· ·					Do not require traceability.	Do not requ	Caps/Plugs	Caps
						ot Number.	ed by "Lo	Located on the bag followed by "Lot Number."	Located on	Snap Rings	Snap
					box label.	date on the	ber and o	Use their work order number and date on the box label	Use their w	Flare Tubes	Flare
					etter "M."	g with the le	, starting	Located on the spool label, starting with the letter "M."	Located on	Copper Tubing	Coppe
					ord "heat."	above the w	directly a	Located on the box label, directly above the word "heat."	Located on	Brazing Rings	Brazir
					x quantity.	el under bo	box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
AIN	C-RING	1				bers	lity Num	Distinguishing Traceablity Numbers	Distingu		
NIA	C-15		la					2		Order Qty	Orde
No(s)	component(s)	Cor		TC	devices, LLC	4		395971	39	Order No.	Ord
Heat Lot/Traceability					0			CTO-V	?		rai