										1		
									5 Training6 Meeting			
	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted	nce	1 Maintenance 2 Tooling			
		t Inspection Record	First Part I					ne Codes	Down Time Codes	ctions	Special Notes / Instructions	Specia
												ROUTING:
D												
>	3											
	172.40											
						1						
									3		56	1/20
Scrap Scrap	2	Notes			Down Time Code	Down Time	Cum. Total		Total Pcs.	Prod Hrs.	Emp. Name	Date
	Thru- put/8hrs		Pcs./Hr			Cycle Time	. 6	Setup Hrs.			Mach. No.	
								ility.	Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	Located on the bag followed by "Lot Number."	owed by	the bag foll	Located on	Snap Rings	Snap
						box label.	Use their work order number and date on the box label.	umber an	ork order nu	Use their w	Flare Tubes	Flare
						etter "M."	_ocated on the spool label, starting with the letter "M."	bel, start	the spool la	Located on	Copper Tubing	Coppe
						vord "heat."	Located on the box label, directly above the word "heat."	el, directl	the box lab	Located on	Brazing Rings	Brazir
						x quantity.	Six digit no. located on the box label under box quantity.	the box I	. located on	Six digit no	Flare Nuts	Flare
	N/A	DCN516-HT	Do				umbers	eablity Nu	Distinguishing Traceablity Numbers	Disting		
Į	396592	2803-12-1/4-0	280						3		Order Qty	Orde
•	No(s)	Component(s)	Cor		LLC	devices, LLC	C C		397586	35	Order No.	Ord
7	Heat Lot/Traceability		,			1			2803-12-1/4	2803	Part No.	Par