			Specia	ROUTING:								12-73-1S	Date	があるが		Caps	Snap	Flare	Coppe	Brazir	Flan		Ord	Ord	Pai
			Special Notes / Instructions									CW	Emp. Name	Contraction	Mach. No.	Caps/Plugs	Snap Rings	Flare Tubes	Copper Tubing	Brazing Rings	Flare Nuts		Order Qty	Order No.	Part No.
			uctions										Prod Hrs.			Do not requ	Located on	Use their w	Located on	Located on	Six digit no.	Distingu		39	-T0/
10000	s setup4 FAIR5 Training		Down Time										Total Pcs.			Do not require traceability.	Located on the bag followed by "Lot Number."	Use their work order number and date on the box label.	Located on the spool label, starting with the letter "M."	Located on the box label, directly above the word "heat."	Six digit no. located on the box label under box quantity.	Distinguishing Traceablity Numbers	4	395006	701-3-5/16-R
			Codes										Cum	nrs.	Setup	×	/ed by "Lo	ber and d	l, starting	directly al	e box labe	olity Numb			
	Date Part Submitted	Date Part Submitted											Cum. Total	SANDERSON.			t Number.	ate on the	with the I	bove the v	l under bo	ers	A		
		Time Of Day									1		Down Time	Time	Cycle		-	box label.	etter "M."	vord "heat."	ox quantity.			devices, LLC	22700
		Approved Yes / No											Down Time Code											LLC	1
		Mtrl Check																							
	T . T -	Rev Letter	irst Part In												Pcs./Hr							_	70	Com)
	,	Inspector	First Part Inspection Record			7	17/						Notes									G-RING	701-3-5/16	component(s)	
						657	234	13. 13.	7	\				put/8hrs	Thru-							とのし	7.	0.00	Heat Lo
	Notes														3						151 SOY	D	No(s)	Heat Lot/Traceability	
			(P								Scrap												TV	
													Scrap Code												