									Training Meeting	6 5		
10/16	1:00Pm 1/10	MI							Setup FAIR	8 4		
35	Notes	Inspector	Rev Letter	Mtrl Check	Approved Yes / No	Time Of Day	Date Part Submitted			2 1		
		Inspection Record	First Part In					Codes			Special Notes / Instructions	Specia
(												ROUTING:
7				g/.							22	
2												
		7										
	<i>\( \)</i> .	コンク										
	\ -	5										
	À.											
	2											
	4											
												Q
B						6	10	15	021	4	55	112/16
Scrap		Notes			Down Time Code	Down Time	Cum. Total	Cum	Total Pcs.	Prod Hrs.	Emp. Name	Date
	par/oillo					imic	official substitution of the substitution of t		despetation and the			
	Thru-		Pcs./Hr			Cycle		Setup Hrs.			Mach. No.	
									Do not require traceability.	Do not requ	Caps/Plugs	Caps
						=	ot Number.	ed by "Lo	Located on the bag followed by "Lot Number."	Located on t	Snap Rings	Snap
		CP13				box label.	date on the	ber and o	Use their work order number and date on the box label	Use their wo	Flare Tubes	Flare
		BRZ05				etter "M."	with the h	l, starting	Located on the spool label, starting with the letter "M."	Located on t	Copper Tubing	Coppe
		BRZ01	M			ord "heat."	bove the w	directly a	Located on the box label, directly above the word "heat."	Located on t	Brazing Rings	Brazin
		UTU-14-1/4	CU			x quantity.	el under bo	e box lab	Six digit no. located on the box label under box quantity.	Six digit no.	Flare Nuts	Flare
		CUTU-3-1/2	כר				bers	olity Num	Distinguishing Traceablity Numbers	Distingu		
		SF4-4-2		l.					300	3	Order Qty	Orde
	No(s)	component(s)	Col		LLC	devices, LLC	THE STATE OF		399085	399	Order No.	Ordo
bility	Heat Lot/Traceability	550505t(c)	2			ontrol ontrol			54-4-2-14	34-4	Part No.	Par